

User Manual

Real-Time Ethernet Kit

Analysis Examples



Hilscher Gesellschaft für Systemautomation mbH

www.hilscher.com

DOC081202UM04EN | Revision 4 | English | 2012-11 | Released | Public

Table of Contents

1	INTRODUCTION	4
1.1	About the User Manual	4
1.1.1	List of Revisions	4
1.1.2	Conventions in this Manual	5
1.1.3	Further Information	6
1.2	Legal Notes	7
1.2.1	Copyright	7
1.2.2	Important Notes	7
1.2.3	Exclusion of Liability	8
1.2.4	Warranty	8
1.2.5	Export Regulations	9
2	METHODS OF MEASUREMENT AND EXAMPLES	10
2.1	Methods of Measurement	10
2.2	Overview of Measuring Examples	10
3	CONDITIONS FOR PERFORMING THE MEASUREMENTS	11
3.1	Hardware and Software Installation	11
3.2	Capture of the Data Frames	11
3.3	Arranging netANALYZER	12
3.3.1	Settings for Recording of Telegrams	13
3.4	Scaling in the Timing Analysis Window	14
3.4.1	Scaling with Sliders	14
3.4.2	Scaling with the Mouse	15
4	PROFINET IO ANALYSIS	16
4.1	Hardware Assembly	16
4.2	Preparing and Performing the Time Measurement	17
4.2.1	Preparing Time Measurement	17
4.2.2	Adjusting Filter Settings	18
4.2.3	Determining Direction of Signal Flow	22
4.2.4	Settings in the Analysis Windows	24
4.2.5	Performing Measurement	25
4.3	Performing Data Capture	28
4.4	Performing a Network Load Analysis	33
4.4.1	Preparing Network Load Analysis	33
4.4.2	Adjusting Filter Settings	34
4.4.3	Starting the Netload Analysis	38
5	ETHERCAT ANALYSIS	41
5.1	Hardware Assembly	41
5.2	Preparing and Performing the Time Measurement	42
5.2.1	Preparing Time Measurement	42
5.2.2	Adjusting Filter Settings	43
5.2.3	Settings in the Timing Analysis Windows	44
5.2.4	Performing Measurement	46

5.3	Performing Data Capture	52
6	ETHERNET/IP ANALYSIS	56
6.1	Hardware Assembly	56
6.2	Performing Data Capture	57
6.2.1	Determining Connection ID	61
6.3	Preparing and Performing the Time Measurement	62
6.3.1	Preparing Time Measurement	62
6.3.2	Adjusting Filter Settings	63
6.3.3	Settings in the Timing Analysis Windows	68
6.3.4	Performing the Measurements	69
6.4	Performing Data Capture	74
6.5	Preparing and Performing a Network Load Analysis	78
6.5.1	Preparing Network Load Analysis	78
6.5.2	Adjusting Filter Settings	78
6.5.3	Performing the Netload Analysis	81
7	SERCOS III ANALYSIS	84
7.1	Hardware Assembly	84
7.2	Preparing and Performing the Time Measurement	85
7.2.1	Preparing Time Measurement	85
7.2.2	Adjusting Filter Settings	86
7.2.3	Settings in the Timing Analysis Windows	88
7.2.4	Performing the Measurements	90
7.3	Performing Data Capture	95
8	MODBUS/TCP ANALYSIS	99
8.1	Hardware Assembly	99
8.2	Preparing and Performing the Time Measurement	100
8.2.1	Preparing Time Measurement	100
8.2.2	Adjusting Filter Settings	101
8.2.3	Settings in the Timing Analysis Windows	106
8.2.4	Performing the Measurements	108
8.3	Performing Data Capture	112
8.4	Preparing and Perform a Network Load Analysis	117
8.4.1	Preparing Network Load Analysis	117
8.4.2	Adjusting Filter Settings	117
8.4.3	Performing the Network Load Measurement	121
9	GLOSSARY	124
10	APPENDIX	125
10.1	List of Figures	125
10.2	List of Tables	127
10.3	Contacts	128

1 Introduction

1.1 About the User Manual

This user manual contains descriptions of measurement examples, which can be build up with the components of the Real-Time Ethernet Kit.

1.1.1 List of Revisions

Index	Date	Chapter	Revisions	Index
2	2009-03-10	Real-Time-Ethernet-Kit	all	Created.
3	2010-07-01	Real-Time-Ethernet-Kit	all	Adaption to netANALYZER, software version 1.3.0.0 and to CIFS 50-RE Rev 3.
4	2012-11-19	Real-Time-Ethernet-Kit	all	Adaption to netANALYZER, software version 1.4.x.x New functions: Netload analysis, history display.

Table 1: List of Revisions

1.1.2 Conventions in this Manual

Operation instructions, a result of an operation step or notes are marked as follows:

Operation Instructions:

➤ <instruction>

or

1. <instruction>

2. <instruction>

Results:

↻ <result>

Notes:



Important: <important note>



Note: <note>



<note, where to find further information>

Positions in Figures

The *Positions* ①, ②, ③ ... or a, b, c ... or A, B, C ... refer to the figure used in that section. If the numbers reference to a section outside the current section then a cross reference to that section and figure is indicated.

1.1.3 Further Information



In this document the following user manuals are referenced

netANALYZER-Card PCI RTE - NANL-C500-RE,
netANALYZER-Box PCIe RTE - NANL-B500E-RE,

and netANALYZER-Software, SW Version 1.4.x

cifX-Karten Real-Time-Ethernet

NXIO 50-RE-Board User manual

*Real-Time Ethernet Kit: Communication systems for Real-Time
Ethernet Installation, Operation and Configuration*



Note: The interconnection of the NXIO 50-RE boards as shown in the measurement examples is only permitted for laboratory conditions.



Note: Take care of the remarks on the installation of wireshark in the netANALYZER User Manual Rev. 12, section 14.3.

1.2 Legal Notes

1.2.1 Copyright

© Hilscher, 2008-2012, Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying material (user manual, accompanying texts, documentation, etc.) are protected by German and international copyright law as well as international trade and protection provisions. You are not authorized to duplicate these in whole or in part using technical or mechanical methods (printing, photocopying or other methods), to manipulate or transfer using electronic systems without prior written consent. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. The included diagrams do not take the patent situation into account. The company names and product descriptions included in this document may be trademarks or brands of the respective owners and may be trademarked or patented. Any form of further use requires the explicit consent of the respective rights owner.

1.2.2 Important Notes

The user manual, accompanying texts and the documentation were created for the use of the products by qualified experts, however, errors cannot be ruled out. For this reason, no guarantee can be made and neither juristic responsibility for erroneous information nor any liability can be assumed. Descriptions, accompanying texts and documentation included in the user manual do not present a guarantee nor any information about proper use as stipulated in the contract or a warranted feature. It cannot be ruled out that the user manual, the accompanying texts and the documentation do not correspond exactly to the described features, standards or other data of the delivered product. No warranty or guarantee regarding the correctness or accuracy of the information is assumed.

We reserve the right to change our products and their specification as well as related user manuals, accompanying texts and documentation at all times and without advance notice, without obligation to report the change. Changes will be included in future manuals and do not constitute any obligations. There is no entitlement to revisions of delivered documents. The manual delivered with the product applies.

Hilscher Gesellschaft für Systemautomation mbH is not liable under any circumstances for direct, indirect, incidental or follow-on damage or loss of earnings resulting from the use of the information contained in this publication.

1.2.3 Exclusion of Liability

The software was produced and tested with utmost care by Hilscher Gesellschaft für Systemautomation mbH and is made available as is. No warranty can be assumed for the performance and flawlessness of the software for all usage conditions and cases and for the results produced when utilized by the user. Liability for any damages that may result from the use of the hardware or software or related documents, is limited to cases of intent or grossly negligent violation of significant contractual obligations. Indemnity claims for the violation of significant contractual obligations are limited to damages that are foreseeable and typical for this type of contract.

It is strictly prohibited to use the software in the following areas:

- for military purposes or in weapon systems;
- for the design, construction, maintenance or operation of nuclear facilities;
- in air traffic control systems, air traffic or air traffic communication systems;
- in life support systems;
- in systems in which failures in the software could lead to personal injury or injuries leading to death.

We inform you that the software was not developed for use in dangerous environments requiring fail-proof control mechanisms. Use of the software in such an environment occurs at your own risk. No liability is assumed for damages or losses due to unauthorized use.

1.2.4 Warranty

Although the hardware and software was developed with utmost care and tested intensively, Hilscher Gesellschaft für Systemautomation mbH does not guarantee its suitability for any purpose not confirmed in writing. It cannot be guaranteed that the hardware and software will meet your requirements, that the use of the software operates without interruption and that the software is free of errors. No guarantee is made regarding infringements, violations of patents, rights of ownership or the freedom from interference by third parties. No additional guarantees or assurances are made regarding marketability, freedom of defect of title, integration or usability for certain purposes unless they are required in accordance with the law and cannot be limited. Warranty claims are limited to the right to claim rectification.

1.2.5 Export Regulations

The delivered product (including the technical data) is subject to export or import laws as well as the associated regulations of different countries, in particular those of Germany and the USA. The software may not be exported to countries where this is prohibited by the United States Export Administration Act and its additional provisions. You are obligated to comply with the regulations at your personal responsibility. We wish to inform you that you may require permission from state authorities to export, re-export or import the product.

2 Methods of Measurement and Examples

2.1 Methods of Measurement

All methods of measuring have a time resolution of 10 ns. Start time and duration of measurement can be controlled by external signals.

Data Recording

With data recording, it is possible to store every telegram in network segment into a file. The telegrams can be selected according to some particular criteria.

Time Measurements

By time measurements, it is also possible when which telegrams occur with which frequency, and how much time the telegrams need between to points in the network.

Analysis of Network Load

The network load analysis enables you to measure the network load of different protocols on the Ethernet line. This shows up, which telegram types occur when and cause which network load. The network load analysis thus allows to identify and visualize unusual events.

In order to avoid erroneous measurements, take care of activating only one single port for the measurements and thus preventing double measurements.

2.2 Overview of Measuring Examples

Protocol	Type of measurement	Measurement
PROFINET IO	Time measurement using a hardware filter	Cycle time, time delay of telegram passing through an IO device.
	Recording of telegrams	Telegram storage with a filter, data conversion for Wireshark.
	Network Load	Start-up time of PROFINET with filter on particular PROFINET telegrams.
EtherCAT	Time measurement using a hardware filter	Cycle time, time delay of telegram passing through a slave and propagation time through a ring.
	Recording of telegrams	Telegram storage with a filter, data conversion for Wireshark.
EtherNet/IP	Time measurement using a hardware filter	Cycle time master, cycle time slave, propagation time master, propagation time slave.
	Recording of telegrams	Telegram storage with a filter, data conversion for Wireshark.
	Network Load	Start-up time of EtherNet/IP, ping as disturbance on the network.
sercos	Time measurement using a hardware filter	Propagation time through primary ring, ConClk cycle time at slave.
	Recording of telegrams	Telegram storage with a filter, data conversion for Wireshark.
Modbus/TCP	Time measurement using a hardware filter	Response time, propagation time, cycle time.
	Recording of telegrams	Telegram storage with a filter, data conversion for Wireshark.
	Network Load	Start-up time of network and ping.

Table 2: Overview of Measuring Examples

3 Conditions for performing the Measurements

3.1 Hardware and Software Installation

1. The PC card cifX and associated software must be installed. Details for the application can be found in the PC card cifX user manual.
2. The netANALYZER hardware and associated software must be installed. Details for use of the netANALYZER software can be found in the netANALYZER user manual.

Additional Documents

Please refer especially to the *User manual Real-Time Ethernet Kit - Communication Systems for Real-Time Ethernet Installation, Operation and Configuration* which is included in this kit. This document describes the hardware and software installation of the individual components (CIFX 50-RE and NXIO 50-RE). The instructions described in it are preconditions for carrying out these measurements and data capturing.

Details of the Freeware software e. g. Wireshark that is used here can be taken from the documentation of the corresponding product.

3.2 Capture of the Data Frames

In order to show the captured data contents, it is necessary to install a network monitoring program that supports the WinPcap format such as Wireshark. Wireshark is "free software", it can be downloaded from the following Internet address: <http://www.wireshark.org/> respectively <http://www.wireshark.org/download.html>. A special Hilscher Dissector is integrated in Wireshark.



Note: GPIO events of the NANL-C500-RE card are decoded by Wireshark from Version 1.0.0. If the display in Wireshark does not appear as "Hilscher- netANALYZER-GPIO-Event" after a new installation, then the corresponding protocol must be enabled in Wireshark as a one-time occurrence.



Note: In addition, a plug-in must be installed in Wireshark Versions before 1.7.1 which can be found on the netANALYZER DVD. For this purpose see also section 6.4 "Display and Settings in Wireshark" of the netANALYZER user manual rev. 12.



Note: If a .pcap file contains a netANALYZER Info Block and if this plug-in is not or is incorrectly installed then Wireshark (Version number ≤ 1.6) could incorrectly interpret the additional data at the end of the frame and show an incorrect frame. In this case de-enable either the generation of the Info Block or, better yet, install the netANALYZER plug-in.

An existing Info Block with a non-installed plug-in is recognized by the message “netANALYZER frame info block” at the end of the frame.

```

0000  01 0e cf 00 01 02 00 b2 23 34 45 00 88 92 00 80  ....#4E....
0010  e7 90 3f 3b 00 00 00 00 00 06 21 38 04 89 00 00  ..?;.....!8....
0020  00 00 00 00 02 16 00 00 00 00 00 00 00 00 00 00  .....
0030  00 00 00 00 00 00 00 00 00 00 00 00 00 04 0a 00  .....
0040  00 00 00 09 38 44 4c 00 06 06 00 00 00 00 00 00  ....8DL.....
0050  08 06 00 00 00 00 00 00 00 00 db 00 00 01 6e 65  .....ne
0060  74 41 4e 41 4c 59 5a 45 52 20 66 72 61 6d 65 20  tANALYZER frame
0070  69 6e 66 6f 20 62 6c 6f 63 6b 01 00 00 00 00 00  info block.....

```

In the following some measurement examples for various Real-Time Ethernet protocols are described. This represents only a small sample of the measurement possibilities of the netANALYZER in order to show the principles of the application.

These measurement examples are built up with the CIFX 50-RE, NXIO 50-RE and netANALYZER hardware components and the associated cables.

3.3 Arranging netANALYZER

➤ Start the netANALYZER software with **Start > Programs > netANALYZER > netANALYZER**.

➤ The main window appears.




Figure 1: netANALYZER Main Window

3.3.1 Settings for Recording of Telegrams

- Select **Settings > File Settings** ① (see Figure 1).
- The window for configuring the paths and the file names of the .hea files opens.




Figure 2: netANALYZER File Settings

GUI element		Description	Allowed range of values / Value
①	Max. number of .hea-files	Maximum number of * .hea files to be stored until capturing is interrupted.	Standard file size: 1GB
②	Ring-buffer mode	If checked, the captured data will be stored within the ring buffer. If not checked, the captured data will be stored within a stack buffer (stack buffer mode). In this mode the capturing process is automatically finished if all *.hea files (i.e. the number of *.hea files specified under ①) are full.	checked / not checked, Default: checked
③	Name of .hea-files	Denomination for * .hea files.	1 .. 255 characters
④	Path of .hea-files	Path to be specified by the user, under which the netANALYZER driver should store the binary file (*.hea).	
⑤	OK	The settings are stored and the window is closed.	

Table 3: Description File Settings

In this window you decide how many files are stored for capturing at which location.

In this context, please also read section 8.4 of the *User Manual netANALYZER*.

3.4 Scaling in the Timing Analysis Window

3.4.1 Scaling with Sliders

There is the possibility to expand or compress the graphical representation of both time axes. This should have the highest importance for the X time axis within the history window.

- For manual scaling switch off the **Auto Scale** feature ⑦.




Figure 3: Timing analysis, change scaling

The time axis ① displays the entire measuring time period within the figure above.

The slider ② allows changing the width of the displayed time period.

The slider ③ allows changing the position of the displayed time period relative to the entire measuring time period.

This applies for the Y time axis accordingly:

The width of the displayed time period is adjusted with slider ④ and the position on the time bar with slider ⑤. The measured events can very easily move outside of the displayed area.

By clicking **Auto Scale** ⑦ the display area is moved over the events again.

Within the histogram, the X axis can be switched between linear and logarithmic scaling by selecting entry **Axis** ⑥ from the combo box and vice versa.

All 3 axes of the figure above can be adjusted with **Auto Scale** in such a manner, that all measuring events are located within the display area.

3.4.2 Scaling with the Mouse

You can zoom areas by holding the left mouse button pressed.




Figure 4: Timing Analysis, scaling with the Mouse

- Switch off **Auto Scale** ⑦.
- Mark an area ⑨ with the left mouse button being pressed either horizontally in window area **A 1** or vertically in window area **A 2**.
- After releasing the mouse button the area within both partial windows is zoomed.
- In order to return to the original display, switch on **Auto Scale** ⑦ again.

4 PROFINET IO Analysis

The following timing parameters are to be measured here as an example:

- measuring the cycle time which the IO Controller uses to send a frame to an IO Device,
- measuring the time a frame running through Device 1 for the frame of the Controller to Device 2,
- measuring the network load for PROFINET IO telegrams at network start-up and at “ping”.

4.1 Hardware Assembly

The following hardware assembly is required for this measurement example.




Figure 5: PROFINET IO Analysis, Hardware Assembly

The MAC addresses that apply for the assembly are listed above the components.

Please ensure that the respective MAC addresses are unique in the world. For this reason the devices in your measurement assembly have different MAC addresses.



Note: The settings for the cifX card and the NXIO 50 board must be accomplished in accordance with section 6.2 of the *User manual Real-Time Ethernet Kit - Communication Systems for Real-Time Ethernet Installation, Operation and Configuration*.

4.2 Preparing and Performing the Time Measurement



Note: The cifX card and the NXIO boards offer auto-crossover functionality. For this reason interchanging the cable at the netANALYZER at TAP A (Port 0 and Port 1) as well as at TAP B (Port 2 and Port 3) is without meaning. Thus, also with the display of the analysis values of the Port designation 0/1 or 2/3 can be seen as interchangeable.



Note: Only the immediately required settings for this measurement assembly of the netANALYZER are described here. Detailed information on the setting and display possibilities of the software can be found in the in the *User Manual netANALYZER NANL-C500-RE*.

4.2.1 Preparing Time Measurement

It is intended to measure the cycle time of frames of the cifX card to Device 2 and the device propagation time from Device 1 for these frames.

➤ Start the netANALYZER software with **Start > Programs > netANALYZER > netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 6: netANALYZER Entry Screen

The respective linkage status (as shown for ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 16) has been completed and the communication between the cifX card and the NXIO board is running. You can see in line **Filter** ② whether there is any filter active on this input line.

4.2.2 Adjusting Filter Settings

- Select **Settings > Filter Settings** ③ to adjust the following settings.
- The filter window appears as follows:




Figure 7: netANALYZER Filter Settings (1)

In order to adjust the settings required for measurement, proceed as follows:




Figure 8: netANALYZER Filter Settings (2)

- Double click onto the menu entry **Filters > User defined** ①.
- The entry **Blank** ② appears.
- Select the line **Blank** ② using the left mouse button.
- Click **Copy Filter** ③.
- The new entry ④ appears under the filter selection.
- Choose a new name for the filter to be created (here PN_F_A).
- Click at **Enable Filter A** ⑤.

Target MAC Address

- Fill in the Target MAC Address of the device ⑥ to which the data are sent into the first 6 bytes of the value line of the filter. Take care of filling in the addresses of the used devices.

Source MAC Address

- Fill in the Source MAC Address of the data packets **7** beginning with byte 0x6 up to byte 0xB of the value line. Take care of filling in the addresses of the used devices.

Filter mask

- Fill in „FF“ **8** into the mask fields below target and source address in order to include every character of the target and source address into the comparison.
- Take care of the entry **Accept, if Filter A matches** **9** being checked within the specified selection line in order to include only those data packets, for which the selection matches.
- Click at **Select Filters** **10**.
In order to make these filter settings effective for all ports click **Apply to All Ports** **11**.
- Store the filter settings by clicking **Save Filter** **12**.
- Leave the filter settings by clicking **OK** **13**.



Note: The MAC addresses have to be adapted to your devices for your measuring assembly.

➤ The main window of the netANALYZER opens:




Figure 9: netANALYZER, Selection Timing Analysis

➤ Select **Timing Analysis** ①.

- In the foreground, the window for graphic presentation of the Timing Analysis opens:



Figure 10: netANALYZER Measurement Window

The timing analysis window is divided into 4 subwindows consisting of two parts, namely histogram and history. In the further discussion of this measuring set-up usually we concentrate on only one of these 4 subwindows.

The size of the single subwindows can be changed by dragging the point where the window division lines cross.

It is also possible to display only the history window or only the histogram window. You can adjust this in the main window of the netANALYZER under **Settings > Analysis Configuration**.

4.2.3 Determining Direction of Signal Flow

- Click the main window of the netANALYZER:
- Click **Start** and then click **Stop** (this is now situated at the position of the **Start**) so that some frames can be displayed.

This is necessary in order to determine on which Ports the analyzer board will detect the frames.

- The main window should now look as follows:




Figure 11: netANALYZER Main Window after Measurement Cycle

Under **TAP A** there is now be seen in the row **Frames received OK** under Port 0 or Port 1 a quantity greater than (here Port 0). This port is important for the settings in the Timing Analysis window and is denominated as active port TAP A in the following.

Under **TAP B** there is now be seen in the row **Frames received OK** under Port 2 or Port 3 a quantity greater than (here Port 2). This port is important for the settings in the Timing Analysis window and is denominated as active port TAP B in the following.



Note: Because of the Auto crossover functionality of the Ethernet PHYs of the devices, it is possible with a restart of the measurement assembly for the Ports 0 and 1 or 2 and 3 to be interchanged.

- Change to the **Timing** Analysis window.

4.2.4 Settings in the Analysis Windows

4.2.4.1 Settings for Analysis Window A

In order to measure the cycle time of the request telegrams at Device 2:

- Adjust the following settings in sub window A:




Figure 12: netANALYZER Measurement Window Settings 1

In this row you can enter a name for the measurement ①.

In **From**: select the active port TAP A (here **Port 1**) ② (as determined in section *Determining Direction of Signal Flow* page 22).

In **To**: select the active port TAP A (here **Port 1**) ③ (as determined in section *Determining Direction of Signal Flow* page 22).

With this setting the cycle time (selected via the filter) of the frames is measured. At this port we have detected the telegrams directed to Device 2 within Figure 11.

Here the scaling of the Y axis can be switched between linear and logarithmic scaling ④.

Ensure that the time axis **Auto Scale** ⑤ is set. This causes the results always to be displayed within the visible part of the window.

4.2.4.2 Adjust the Settings in Window B

In this example, the propagation time of telegrams through Device 1 shall be measured.

- To do so, make the following settings:




Figure 13: netANALYZER Measuring Window Settings 2

In this row you can enter a name for the measurement ①.

In **From**: select the active port TAP A (here **Port 1**) ② (as determined in section *Determining Direction of Signal Flow* page 22).

In **To**: select the active port TAP B (here **Port 3**) ③ (as determined in section *Determining Direction of Signal Flow* page 22).

Ensure that the time axis **Auto Scale** ⑤ is set. So you assure that the results will always be displayed within the visible part of the window.

4.2.5 Performing Measurement

- Click into the main window of the netANALYZER.




Figure 14: netANALYZER Main Window Start/Reset

- Click **Reset** (1). This deletes the previously displayed time data.
- On **Start** (2) to start the analysis.
- The former Start button now becomes the Stop button.
The graphical display of measurement values can be observed instantaneously.

In the example displayed here, an evaluation has been made over a time of approximately 30 minutes. In this way the following figures have been generated.

- Wait for the time in which you would like to evaluate frames.
- Click **Stop**.
- You will now find the following information in the subwindow A of the Timing Analysis window.

4.2.5.1 Result of Measurement in Subwindow A




Figure 15: netANALYZER PROFINET IO Cycle time Measurement, auto-scale

- Switch off **Auto Scale** (1) in order to adjust the optimal scale and time period with the sliders in the partial displays.
- (2) The number of analyzed frames (123066).

③ The minimum cycle time in **ns** (with separation into groups of thousands), followed by the deviation to the average time specified in %.

④ The average cycle time in **ns** (with separation into groups of thousands).

⑤ The maximum cycle time in **ns** (with separation into groups of thousands), followed by the deviation to the average time specified in %.

The max. and min. time values 16,03 ms and 15,97 ms indicate extreme values. In figure „A 1“ (the histogram) you can realize, that most of the telegrams are located within a significantly more narrow time window between approx. 15,992 ms ⑥ and 16,008 ms ⑦.

Within the history window „A 2“ you can find the time frames where the rare events with large deviations by shifting the sliders ⑧ (Scaling) and ⑨ (Time frame). These are tagged here as ⑩ and ⑪.

4.2.5.2 Result of Measurement in Subwindow B

➤ In window B of the timing analysis window you can now find the following information:




Figure 16: PROFINET IO, Device 1 Propagation time

➤ Switch off **Auto Scale** ①, in order to adjust optimal scaling and time frame with the sliders within the partial displays.

② The number of telegrams being analyzed amounts to 123067.

③ The minimum cycle time in **ns** (with separation into groups of thousands), followed by the deviation to the average time specified in %, here 7,77 μ s.

④ The average propagation time in **ns** (with separation into groups of thousands), here 7,838 μ s.

⑤ The maximum propagation time in **ns** (with separation into groups of thousands) and following percentage value of the average measured time (here 8,55 μ s und 9,08 %).

This percentage value of the deviation seems to be very high at first sight.

However, if you switch axis ⑥ to logarithmic representation, then you can see in figure „B 1“ that only very few telegrams cause this deviation. In the history display „B 2“ you can see by shifting the sliders ⑧ (Scaling) and ⑨ (Time frame), that these events all occur in a very short time period ⑦.

By increasing the resolution of the time scale of the history display even more, you can also determine the absolute time of these events.




Figure 17: PROFINET IO, Device 1 Propagation Time, History extremely scaled

4.3 Performing Data Capture

Both the frames of the cifX card to Device 2 and the response frames from Device 2 to the cifX card are to be captured.

Preconditions:

- The hardware assembly as described in section *Hardware Assembly* on page 16 must have been set up,
- the settings for the cifX card must have been made,
- data exchange between the cifX card and the Devices must have been established.

➤ Start the netANALYZER software with **Start > Programs > Hilscher GmbH > Hilscher netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 18: Main Window for Telegram Recording

The respective linkage status (as shown for ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 16) has been completed and the communication between the cifX card and the NXIO boards is running.

If the filter settings from the timing analysis are still active, this will be tagged with the label **ACTIVE** ②. Check the filter settings for correctness!

➤ Proceed from the main window of the program to the filter settings using the **Settings > Filter Settings** dialog.

➤ The filter window appears as follows:




Figure 19: netANALYZER PROFINET IO Filter Settings

- Adjust the settings shown above:
 - Open the **User defined** filter setting (1) which you have already created during the timing analysis.
 - Select the stored filter **PN_F_A** (4) as defined in section *Preparing Time Measurement* on page 17.
 - Check the checkbox **Select Filter** (10).
 - Click **Apply to All Ports** (11).
 - Verify, that this filter setting is really valid for each port.
 - Leave the window with **OK** (13).
- You are returned to the main window.




Figure 20: Start Data Capture

- Ensure that **Capture data** (4) is turned on.
- Start the capture with a click **Start** (5).
- The **Start** (5) button becomes the **Stop** (5) button.
- Wait until a sufficient number of frames have been captured.
- Click **Stop** (5).

➤ Click **Convert** ⑥.

➤ The following window appears:





Figure 21: pcap Conversion 1

The pcap conversion window consists of 2 columns:

Window Area ①

User Interface Element	Description
Path ①	Path to be defined by the user from which the netANALYZER shall read the binary file (*.hea) for conversion. The settings, which are done here, have an effect to the next capture. The settings done at Settings > File Settings are changed with it.
Button ②	Selection button for the selection of the source directory of the .hea files.
All filtered .hea files for this name or capture ③	List of .hea files in the selected directory.

Window Area B

User Interface Element	Description
Path 3	Path to be defined by the user where the netANALYZER software shall store the converted WinPcap file (*.pcap)
Button 4	Selection button for the selection of the target directory for storing the .pcap files
File name 5	Systematic file denomination for the .pcap files. The netANALYZER software additionally appends a running number for each file within the filename.
.pcap files that will be generated D	<p>Preview of generated .pcap files The name structure is as follows:</p> <div style="display: flex; align-items: center;"> <div style="flex: 1;">  </div> <div style="flex: 1; padding-left: 10px;"> <p>13 File name from 5.</p> <p>14 consecutive number.</p> <p>15 Time information, consists of yyyyymmddhhmmss (start of the capture of the file, if check 6 is set).</p> </div> </div>
Append date/time to pcap file name 6	If checked, date and time are added within the file name
Include FCS in .pcap-files 7	<p>Checkbox whether the Ethernet checksum shall be included within the PCAP file or not (Some Wireshark dissectors do not support FCS.)</p> <p>Note: If Convert to extended .pcap file including additional frame information is checked, Include FCS in .pcap-file is grayed out as FCS is always converted into a .pcap file then. FCS = Frame Check Sequence (Ethernet checksum)</p> <p>Not selectable, if option 10 is checked, however active.</p>
Include corrupted frames in .pcap file 8	If this option is activated, then also erroneous frames will be included into the .pcap file. If it is deactivated, only correct telegrams will be stored in the .pcap file.
Append netANALYZER information block (for Wireshark versions before 1.7.1 with additional plug in only) 9	<p>This option requires the installation of the netANALYZER Wireshark plug-in for Wireshark versions < V1.7.1.</p> <p>Adds the netANALYZER info block to the .pcap file after the Ethernet frame. This supplies additional information for each single telegram such as time of receipt, receiving port or error information.</p> <p>Note: The .pcap file format with info block after the Ethernet frame is no longer supported by Wireshark versions ≥ 1.7.1.</p> <p>Not selectable if option 10 is checked.</p>
Convert to extended .pcap file including additional frame information 10	<p>Note: If this item is checked, the extended .pcap file format generated by the netANALYZER software V1.4.x.x can only be opened in Wireshark versions beginning with V1.7.1.</p> <p>Beginning with netANALYZER software V1.4.x.x an extended .pcap file format can be generated. There the netANALYZER info block is stored in the 4 bytes prior to the Ethernet frame. Therefore, additional information for each single telegram such as time of receipt, receiving port or error information is available.</p>
Convert 11	Conversion of binary files into the WinPcap format is started.
Close 12	The window is closed without starting any conversion.

- Select the file to be converted in window area A.
- Add the necessary settings in window area B.
- Click **Convert 11** in order to convert the data into the .pcap file format.
- Open the file with Wireshark.
- The following data will be displayed.

- Double click on the converted file (here c:\Default_001.pcap), or start the Wireshark program and select the file with the **File > Open** path.
- The Wireshark program displays the data as follows:




Figure 22: PROFINET IO netANALYZER Wireshark Telegram Display

According to the filter settings, only telegrams sent from the cifX card to Device 2 have been recorded.

- (A) In this window area all the displayed individual frames will be listed individually. In the **Port** column (1) you will see the Port number of the netANALYZER board in which the frame was captured.
- (B) In this window area the data of the selected frame in the (A) window area is shown at the protocol level. In the row 2 of this window area (2) you will see the Port number of the netANALYZER board at which the frame was captured.
- (C) In this window area the data of the selected frame is shown at the byte level.



Note: In the figure above, the individual frames have been shown twice. The reason is in the assembly of the switching from *Hardware Assembly* on page 16 and the selected filter setting, as the netANALYZER captures the data at each TAP and the filtered frames pass through both Ports. Thus, also the propagation time through Device 1 can also be seen.

4.4 Performing a Network Load Analysis

The network load caused by the cifX card shall be analyzed. Furthermore, the amount of PROFINET protocol packets compared to the amount of packets of other protocols shall be analyzed. Finally, the network start-up behavior shall be examined.

The following requirements apply:

- The hardware must have been set up according to the description within section *Hardware Assembly* on page 16,
- The settings of the cifX card must have been adjusted already.

4.4.1 Preparing Network Load Analysis

The filter criteria must be determined and adjusted subsequently.

- For a short time record data from a running PROFINET network.
- Have a look at a standard PROFINET telegram.
- This data set should look like this:




Figure 23. Standard PROFINET Data Set

In the figure above, the relevant filter data from ① to ④ are tagged.

- ① A Standard PROFINET protocol telegram.
- ② The virtual LAN identifier (0x8100).
- ③ The PROFINET identifier (0x8892).
- ④ The Frame ID tag (0x80 02)
- With the data above an *Extended Software Filter* shall be configured.

4.4.2 Adjusting Filter Settings

- Switch off hardware filter




Figure 24: Switch off hardware filter



Note: The selected hardware filters apply additionally to the *Extended Software Filter*. Therefore uncheck either checkbox **Enable Filter** (1) at the Hardware-Filter or uncheck checkbox **Select Filter** (2).

- Adjust software filter.
 - For the configuration of the *Extended Software Filters* proceed as follows:
 1. In the netANALYZER main menu click at menu entry **Settings > Extended Software Filter Settings**.
- The following configuration window is displayed:




Figure 25: Create Extended Software Filter (1)

2. Create the filter entries. Proceed as follows:

- If the window area (A) contains more than displayed in the figure above, then erase the entries by clicking **Clear Tree** (1).
- Open the selection menu below **Add Filter Entry** (2) and select the entry **Add Byte Match Entry**.
- The following configuration window is opened:




Figure 26: Create Extended Software Filter (2)

- Here you can enter the filter data, that you have investigated within Figure 23 below the entry ②:
In the figure above below ① the byte position (here 12:13; **take care of byte counting beginning at „0“**), below ② the data contents of this (here 81 00) and below ③ the comparison condition (here „=“). Then click **OK** ④.

➤ The *Extended Software Filter* should now look like:




Figure 27: Extended Software Filter after 1. Entry

Proceed as follows for the PROFINET identification:

- Determine the information for entry ③ (PROFINET identification) from Figure 23.
- Tag the entry ① of the filter display above and then add the entry „Bytes [16:17] = 88 92“ with **Add Filter Entry** ② as described already for entry ①.



Note: This generates an AND relation of the filter condition. If you had tagged the entry Start of the figure above, then you would have related both entries with an OR relation.

➤ Now your filter should look like this:




Figure 28: Extended Software Filter after 2. Entry

- In order to display a curve within the Netload Analysis display, you have to add an identification entry.
- To do so, click the entry tagged with ① in the filter display above. Then click **Add Identification Entry**.
- In the opening window enter a name for identification purposes. Here the name „PROFINET“ has been entered.



Note: If other data sets not matching the filter conditions occur during analysis, these will be registered with the identification **Other**.

➤ Then the filter window will look like:




Figure 29. Extended Software Filter after 3. Entry

- Store the filter settings for later applications by clicking **Save Tree** ① and leave the filter window by clicking **OK**.
- You return back into the main window of netANALYZER.



Note: If during the analysis of telegrams further types of telegrams are detected, the analysis will be extended by „Other“.

Adjust the following settings here:




Figure 30: netANALYZER Main Window PROFINET Netload Analysis

- Check the checkbox at TAP A for Port 0 and Port 1 **①**. This is necessary as it is not predictable over which port the communication will start due to the Auto Crossover feature of the Ethernet ports.
- If necessary, uncheck the checkboxes at TAP B **②**, in order to prevent the telegrams from being recorded twice.

4.4.3 Starting the Netload Analysis

- Select **Netload Analysis** **③**.
- The **Netload Analysis** window opens.
- In order to evaluate also the frames not originating from PROFINET during connection establishment, open the Ethernet connection at CH 0 of Device 1 in Figure 5 to be able to close it again after starting the recording of the analysis.
- Select the main window of the netANALYZER.
- Here, click **Start**.
- The recording of analysis data begins.
- Reconnect the cable at CH 0 of the Device.
- After some time, stop recording by clicking **Stop** in the main window of the netANALYZER.
- In the Netload Analysis window you can see information similar to the following:




Figure 31: Netload Analysis for PROFINET Start-up Phase

Line ① in window area A corresponds to line ① in window area B.

Line ② in window area A corresponds to line ② in window area B.

Besides the selection made within the filter settings automatically the rest of the analysis events which is not included by the selection conditions of the filter settings is displayed as **Other** within the graphical display.

Within window area A you can see the numerical values of the recording, Right-click onto a frame type in order to select within the context menu the color of the curve, the type of line and its thickness.

By right-clicking at window area B, you can switch for instance between linear and logarithmic Y-Scaling.

If you follow the curve with the mouse in the window area B, the numerical values of the measurement for this second are displayed ③.




Figure 32: Extended Software Filter with FrameID

Using the following Extended Software filter setting which additionally filters for a specific FrameID you get the following analysis picture for the start-up phase of the PROFINET network.




Figure 33: Netload Analysis for PROFINET Start-up Phase with FrameID 8002

5 EtherCAT Analysis

The following timing parameters are to be measured here as an example:

- measuring the cycle time which the Master uses to access a slave,
- measuring the frame running time through Slave 1,
- measuring the ring propagation time of the frames.

5.1 Hardware Assembly

The following hardware assembly is required for this measurement example.




Figure 34: EtherCAT Analysis, Hardware Assembly



Important! It is important, that Ethernet connector **CH0** of the cifX card is connected to Ethernet connector **CH0** of the NXIO 50 Board.



Note: The settings for the cifX card and the NXIO 50 board must be accomplished in accordance with Section 6.3 of the *User manual Real-Time Ethernet Kit - Communication Systems for Real-Time Ethernet Installation, Operation and Configuration*.

5.2 Preparing and Performing the Time Measurement



Note: The cifX card and the NXIO boards offer auto-crossover functionality. For this reason an interchange of the cable at the netANALYZER at TAP A (Port 0 and Port 1) as well as at TAP B (Port 2 and Port 3) is without effect. Thus, also at the display of the analysis values of the Port designation 0/1 or 2/3 can be considered as interchangeable.



Note: Here only the settings of the netANALYZER immediately required for this measurement assembly are described. Detailed information on the setting and capture possibilities of the software can be found in the *User Manual netANALYZER*.

5.2.1 Preparing Time Measurement

It is desired to measure the cycle time of frames of the cifX card to Slave 1 and the device running time from Slave 1 as well as the ring propagation time.

➤ Start the netANALYZER software with **Start > Programs > netANALYZER > netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 35: netANALYZER Entry Screen

The respective linkage status (as shown for ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 41) has been completed and the communication between the cifX card and the NXIO boards is running.

5.2.2 Adjusting Filter Settings

- Select **Settings > Filter Settings** ③ to adjust the following settings.




Figure 36: netANALYZER Filter Window

- Select **Filters > EtherCAT > All EtherCAT frames** ①.
- Click **Select Filter** ②.
- Click **Apply to All Ports** ③.
- Check whether the selected filter is really applied to all ports.
- Leave the filter settings by clicking **OK** ④.
- You are returned to the netANALYZER main window.
- In the netANALYZER main window select **Timing Analysis** ④.
- The window for graphic representation of the Timing Analysis opens in the foreground:



Figure 37: netANALYZER Timing Analysis window

The timing analysis window is divided into 4 subwindows consisting of two parts, namely histogram and history. In the further discussion of this measuring set-up usually we concentrate on only one of these 4 subwindows.

The size of the single subwindows can be changed by dragging the point where the window division lines cross.

It is also possible to display only the history window or only the histogram window. You can adjust this in the main window of the netANALYZER under **Settings > Analysis Configuration**.

5.2.3 Settings in the Timing Analysis Windows

At first, take care of **Auto Scale** ① being set.




Figure 38: netANALYZER Timing-Auto-Scale

In this way you ensure, that if telegrams are detected these are also visible as bars and are not outside of the window area.

➤ Adjust the From / To conditions for each partial window as follows:



Note: At your test setup, the telegrams may run over the respective corresponding port due to the Auto-Crossover feature of the ports of the netANALYZER card. If necessary adapt the ports according to your setup!

5.2.3.1 Settings for Analysis Subwindow A

In order to measure the cycle time of the telegrams of the cifX card to slave 1.

- Adjust the following settings in sub window A:




Figure 39: Timing Analysis Window A, EtherCAT Cycle Time

- In this row you can enter a name for the measurement. Enter **Cycle time** here.
- In **FROM:** select **Port 0**.
- In **To:** select **Port 0**.
The network cycle time is measured with these settings.
Here the scaling of the Y axis can be switched between linear and logarithmic.
- Ensure that the **Auto Scale** time axis is set.

5.2.3.2 Adjusting the following Settings in Subwindow B

Measurement of Ring Propagation Time



Figure 40: Timing Analysis Window B, EtherCAT Ring Propagation Time (1)

- In **From:** select **Port 0**.
- In **To:** select **Port 1**.

This setting is used to measure the time between the arrival of the frame at Port 0 and the arrival at Port 1. This can be the ring propagation time or the cycle time minus the ring propagation time. This can only be interpreted after successful measurement (see also settings for window 3). This possible ambiguity is the result of the Auto crossover functionality of the cifX card and the NXIO boards.

5.2.3.3 Adjusting the following Settings in Subwindow C

In order to measure the ring propagation time / cycle time:

- Make the following settings in window C.



Figure 41: Timing Analysis Window C, EtherCAT Ring Propagation Time (2)

- In **From:** select **Port 1**.
- In **To:** select **Port 0**.

This setting is used to measure the time between the arrival of the frame at Port 0 and the arrival at Port 1. This can be the ring

propagation time or the cycle time minus the ring propagation time. This can only be interpreted after successful measurement (see also settings for window 2). This possible ambiguity is the result of the Auto crossover functionality of the cifX card and the NXIO boards.

5.2.3.4 Adjusting the following Settings in Subwindow D

In order to measure the signal propagation time of slave 1:

- Make the following settings in window D:




Figure 42: Timing Analysis Window, EtherCAT Ring Propagation Time (2)

- In the **Start Port** select **Port 0** (2) (or possibly **Port 1**).
- In the **Stop Port** select **Port 2** (3) (or possibly **Port 3**).
The signal running time through Slave 1 is found with one of the two setting pairs, with the other setting a size of the cycle time is found.

5.2.4 Performing Measurement

- Click in the main window of the netANALYZER.



Figure 43: netANALYZER Start/Stop Analysis

- Click **Reset** (1). This deletes the previously displayed time data.
- Click **Start** (2) to start the analysis.
- The **Start** button becomes the **Stop** button.
- Wait for the time during which you would like to evaluate the frames.
- Click **Stop**.

5.2.4.1 Measurement Result Window A: Cycle Time

If From- and Stop-Port are identical, always the cycle time will be measured independently from the direction (data path from master to the slaves or from slave to master). Within the data path from the slaves to the master, the jitter may be increased.

- You will now find the following information in window A of the Timing Analysis window.




Figure 44: EtherCAT Timing Analysis Window A with measured Data

In figure „A 1“ (the histogram), the distribution of the number of telegrams is displayed in dependence of the deviation of the cycle time.

In the history window „A 2“, the distribution of the number of telegrams is displayed in dependence of the time.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	0.99 μ s
Av Time	The average cycle time of the telegrams	1000.001 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	1008.170 μ s
Std. Deviation	The standard deviation of the cycle time	1.717 μ s

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of evaluated telegrams	197013
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

The average cycle time is therefore 1 ms. All further measurements that lie within the size range of the cycle time are measurements between to and for paths of the frame. These are usually no meaningful measurements.

5.2.4.2 Measurement Result Window B: Ring Propagation Time

➤ You will now find the following information in window B of the Timing Analysis window.




Figure 45: EtherCAT Timing Analysis Window B with measured Data

In figure „**B 1**“ (the histogram), the distribution of the number of telegrams is displayed in dependence of the ring propagation time.

In the history window „**B 2**“, the distribution of the number of telegrams is displayed in dependence of the time.

At **1** you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	5.49 μ s
Av Time	The average cycle time of the telegrams	5.557 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	5.63 μ s
Std. Deviation	The standard deviation of the cycle time	31 ns

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of evaluated telegrams	197014
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

Here you can see that the average ring propagation time is approximately 5.5 μ s.



Note: Because of the Auto crossover functionality of the Ethernet PHYs of the EtherCAT devices, it is possible with a restart of the installation for the Ports 0 and 1 to be interchanged.

5.2.4.3 Measurement Result Window C: Cycle Time - Ring Propagation Time

➤ You will now find the following information in window C of the Timing Analysis window.




Figure 46: EtherCAT Timing Analysis Window C with measured Data

Here you can see that this is not a meaningful measurement as the found protocol sequence time lies within the range of the cycle time.

From the measurement results in the windows 2 and 3 it can be seen that in this assembly the signals from the Master run through Port 0 in the netANALYZER.

5.2.4.4 Measurement Result Window C: Telegram Propagation Time through Slave 1

➤ You will now find the following information in window D of the Timing Analysis window.




Figure 47: EtherCAT Timing Analysis Window D with measured Data

Here it can be seen that the frame running time was measured through Slave 1.

The single strips are caused by the time resolution of the netANALYZER card amounting 10 ns.

In figure „D 1“ (the histogram), the distribution of the number of telegrams is displayed in dependence of the deviation of the cycle time.

In the history window „D 2“, the distribution of the number of telegrams is displayed in dependence of the time.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	1.16 μ s
Av Time	The average cycle time of the telegrams	1.189 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	1.22 μ s
Std. Deviation	The standard deviation of the cycle time	13 ns

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of evaluated telegrams	197014
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

5.3 Performing Data Capture

The frames of the cifX card to the Slaves and the response frames from the Slaves to the cifX card are to be captured.

Preconditions:

- The hardware assembly as described in section *Hardware Assembly* on page 41 must have been created.
- The settings for the cifX card must be carried out.
- A data exchange between the cifX card and the Slaves must exist.
- The basic settings for the netANALYZER must be carried out as described in section *Preparing Time Measurement* on page 17.

➤ Start the netANALYZER software with **Start > Programs > Hilscher > netANALYZER > netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 48: EtherCAT netANALYZER Main Window

The respective linkage status (as shown for ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 41) has been built up and the communication between the cifX card and the NXIO boards is running then.

- Ensure that the filter is set up according to section *Preparing Time Measurement* as described at page 42 of this document.
- Click **OK**.
- You are returned to the main window.




Figure 49: Start Data Capture

- Ensure that **Capture data** (4) is turned on.
- Start the capture with a click **Start** (5).
- The **Start** (5) button becomes the **Stop** (5) button.
- Wait until a sufficient number of frames have been captured.
- Click **Stop** (5).
- Click **Convert** (6).
- The following window appears:





Figure 50: pcap Conversion 1

The pcap conversion window consists of 2 columns:

Window Area (A)

User Interface Element	Description
Path (1)	Path to be defined by the user from which the netANALYZER shall read the binary file (*.hea) for conversion. The settings, which are done here, have an effect to the next capture. The settings done at Settings > File Settings are changed with it.
Button (2)	Selection button for the selection of the source directory of the .hea files.
All filtered .hea files for this name or capture (C)	List of .hea files in the selected directory.

Window Area B

User Interface Element	Description
Path 3	Path to be defined by the user where the netANALYZER software shall store the converted WinPcap file (*.pcap)
Button 4	Selection button for the selection of the target directory for storing the .pcap files
File name 5	Systematic file denomination for the .pcap files. The netANALYZER software additionally appends a running number for each file within the filename.
.pcap files that will be generated D	<p>Preview of generated .pcap files The name structure is as follows:</p> <div style="display: flex; align-items: center;"> <div style="flex: 1;">  </div> <div style="flex: 1; padding-left: 10px;"> <p>13 File name from 5.</p> <p>14 consecutive number.</p> <p>15 Time information, consists of yyyymmddhhmmss (start of the capture of the file, if check 6 is set).</p> </div> </div>
Append date/time to pcap file name 6	If checked, date and time are added within the file name
Include FCS in .pcap-files 7	<p>Checkbox whether the Ethernet checksum shall be included within the PCAP file or not (Some Wireshark dissectors do not support FCS.)</p> <p>Note: If Convert to extended .pcap file including additional frame information is checked, Include FCS in .pcap-file is grayed out as FCS is always converted into a .pcap file then. FCS = Frame Check Sequence (Ethernet checksum)</p> <p>Not selectable, if option 10 is checked, however active.</p>
Include corrupted frames in .pcap file 8	If this option is activated, then also erroneous frames will be included into the .pcap file. If it is deactivated, only correct telegrams will be stored in the .pcap file.
Append netANALYZER information block (for Wireshark versions before 1.7.1 with additional plug in only) 9	<p>This option requires the installation of the netANALYZER Wireshark plug-in for Wireshark versions < V1.7.1.</p> <p>Adds the netANALYZER info block to the .pcap file after the Ethernet frame. This supplies additional information for each single telegram such as time of receipt, receiving port or error information.</p> <p>Note: The .pcap file format with info block after the Ethernet frame is no longer supported by Wireshark versions ≥ 1.7.1.</p> <p>Not selectable if option 10 is checked.</p>
Convert to extended .pcap file including additional frame information 10	<p>Note: If this item is checked, the extended .pcap file format generated by the netANALYZER software V1.4.x.x can only be opened in Wireshark versions beginning with V1.7.1.</p> <p>Beginning with netANALYZER software V1.4.x.x an extended .pcap file format can be generated. There the netANALYZER info block is stored in the 4 bytes prior to the Ethernet frame. Therefore, additional information for each single telegram such as time of receipt, receiving port or error information is available.</p>
Convert 11	Conversion of binary files into the WinPcap format is started.
Close 12	The window is closed without starting any conversion.

- Select the file to be converted in window area A.
- Add the necessary settings in window area B.
- Click **Convert 11** in order to convert the data into the .pcap file format.
- Open the file with Wireshark.
- The following data will be displayed.

- Double click on the converted file (here `c:\Default_001.pcap`), or start the Wireshark program and select **File > Open**.

The Wireshark program displays the data as follows:




Figure 51: EtherCAT netANALYZER Wireshark Telegram Display

- ① This window area shows a list of all frames.
- ② In this window area you can see individual frame regions of the selected frame.
- ③ In this window area the data of the selected frame is shown at the Byte level.
- ④ Here a complete frame cycle of the measurement assembly is highlighted. The first row contains the frame as it comes from the Master. This was captured at Port 0.
The second row contains the frame after the first Slave on the way to Slaves 2 and 3. This was captured at Port 2.
The third row contains the frame as it returns from Slave 2, after it was already processed by Slave 3. This was captured at Port 3.
The fourth row contains the frame as it is returned from Slave 1 to the Master. This was captured at Port 1.
- ⑤ Here the part of the frame (third row of the cycle) is highlighted that contains the nominal values at the Slave.
- ⑥ Here the part of the frame (third row of the cycle) is highlighted that contains the actual values from the Slave.

6 EtherNet/IP Analysis

The following timing parameters are to be measured here as an example:

- measuring the answer cycle from Slave 3,
- measuring the cycle time of the access of Slave 3,
- measuring the propagation time through Slaves 1 and 2 in both signal directions.

6.1 Hardware Assembly

The following hardware assembly is required for this measurement example.




Figure 52: EtherNet/IP Analysis, Hardware Assembly

The MAC addresses that apply for the assembly are listed above the components.

Please note that the respective MAC addresses are unique in the world. For this reason the devices in your measurement assembly have different MAC addresses.



Note: The settings for the cifX card and the NXIO 50 board must be accomplished in accordance with section 6.4 of the *User manual Real-Time Ethernet Kit - Communication Systems for Real-Time Ethernet Installation, Operation and Configuration*.

6.2 Performing Data Capture

The connection ID of slave 3 for cyclic data transmission has to be determined.

You need this information for the correct filter settings if you want to determine propagation times of slave telegrams with the timing analysis.

➤ In order to register all telegrams, all filters need to be switched off.

To do so, proceed as follows:

- Stop any running data capture.
- In the main window of the netANALYZER select **Settings > Filters Settings**.

➤ The window for filter settings opens:




Figure 53: EtherNet/IP Filter Data Capture

- Select **Port 0** (1).
- Select under **User Defined Blank** (2).
- Check checkbox **Select Filter** (3).
- Make these settings valid for all ports by clicking **Apply to All Ports** (4).
- Click **OK** (5).




Figure 54: EtherNet/IP Data Capture Start

- Take care of all ports being selected for data capturing ①.
- Select **Capture Data** ②.
- Start capturing by clicking **Start** ③.
- Data capturing begins, the start button turns to a stop button.
- Wait until some telegrams have been recorded.
- Click **Stop** ③ and then click **Convert** to convert the data into the pcap format for the analysis with Wireshark.
- The following window opens:




Figure 55: Ethernet/IP netANALYZER Analysis Conversion 1

The window above is subdivided into two areas:

Window Area A.

User Interface Element	Description
Path 1	Path to be defined by the user from which the netANALYZER shall read the binary file (*.hea) for conversion The settings, which are done here, have an effect to the next capture. The settings done at Settings > File Settings are changed with it.
Button 2	Selection button for the selection of the source directory of the .hea files
All filtered .hea files for this name or capture C	List of .hea files in the selected directory

Window Area B.

User Interface Element	Description
Path 3	Path to be defined by the user where the netANALYZER software shall store the converted WinPcap file (*.pcap)
Button 4	Selection button for the selection of the target directory for storing the .pcap files
File name 5	Systematic file denomination for the .pcap files. The netANALYZER software additionally appends a running number for each file within the filename.
.pcap files that will be generated D	Preview of generated .pcap files The name structure is as follows: <div><div><div>File name</div><div>Modbus_TCP_Ping_01 5</div></div><div><div>.pcap files that will be generated:</div><div>Modbus_TCP_Ping_01_00001_20120524090708</div></div><div><div>13</div><div>14</div><div>15</div></div></div> <div><div>13</div> File name from 5.</div> <div><div>14</div> consecutive number.</div> <div><div>15</div> Time information, consists of yyyymmddhhmmss (start of the capture of the hea file, if ckeck 6 is set).</div>

Include FCS in .pcap-files ⑦	<p>Checkbox whether the Ethernet checksum shall be included within the PCAP file or not (Some Wireshark dissectors do not support FCS.)</p> <p>Note: If Convert to extended .pcap file including additional frame information is checked, Include FCS in .pcap-file is grayed out as FCS is always converted into a .pcap file then. FCS = Frame Check Sequence (Ethernet checksum)</p> <p>Not selectable if option ⑩ is checked.</p>
Include corrupted frames in .pcap file ⑧	<p>If this option is activated, then also erroneous frames will be included into the .pcap file. If it is deactivated, only correct telegrams will be stored in the .pcap file.</p>
Append netANALYZER information block (for Wireshark versions before 1.7.1 with additional plug in only) ⑨	<p>This option requires the installation of the netANALYZER Wireshark plug-in for Wireshark versions < V1.7.1.</p> <p>Adds the netANALYZER info block to the .pcap file after the Ethernet frame. This supplies additional information for each single telegram such as time of receipt, receiving port or error information.</p> <p>Note: The .pcap file format with info block after the Ethernet frame is no longer supported by Wireshark versions ≥ 1.7.1.</p> <p>Not selectable if option ⑩ is checked.</p>
Convert to extended .pcap file including additional frame information ⑩	<p>Note: If this item is checked, the extended .pcap file format generated by the netANALYZER software V1.4.x.x can only be opened in Wireshark versions beginning with V1.7.1.</p> <p>Beginning with netANALYZER software V1.4.x.x an extended .pcap file format can be generated. There the netANALYZER info block is stored in the 4 bytes prior to the Ethernet frame. Therefore, additional information for each single telegram such as time of receipt, receiving port or error information is available.</p>
Convert ⑪	<p>Conversion of binary files into the WinPcap format is started.</p>
Close ⑫	<p>The window is closed without starting any conversion.</p>

- Select the file to be converted in window area ①.
- Add the necessary settings in window area ②.
- Click **Convert** ⑪ in order to convert the data into the .pcap file format.
- The window closes after the conversion was completed.
- Open the file with Wireshark.
A double click on the .pcap file opens Wireshark, if the Wireshark program is installed correctly.
- The following data will be displayed:

6.2.1 Determining Connection ID




Figure 56: EtherNet/IP Data Capture

- Select a telegram in window area **A** to be cyclically sent by slave 3.
 - Identify and tag the data set **Connection ID** in window area **B**.
 - In window area **C** this data set is displayed with the data position within
- This information is required for the filter settings to be applied if you want to determine propagation times of slave telegrams with the timing analysis



Important: Do not interrupt the data communication in the measuring setup as with a restart of the data communication, the „Connection ID“ will be changed.

6.3 Preparing and Performing the Time Measurement



Note: The cifX card and the NXIO boards offer auto-crossover functionality. For this reason an interchange of the cable at the netANALYZER at TAP A (Port 0 and Port 1) as well as at TAP B (Port 2 and Port 3) is without meaning. Thus, also with the display of the analysis values of the Port designation 0/1 or 2/3 can be seen as interchangeable.



Note: Here only the settings of the netANALYZER immediately required for this measurement assembly are described. Detailed information on the setting and capture possibilities of the software can be found in the *User Manual netANALYZER NANL-C500-RE*.

As the Ethernet/IP slave sends its input data cyclically to a broadcast address on its own, in this case it is necessary to determine the Connection ID for the cyclic protocols of the slave prior to the measurement

This Connection ID can be determined by a data recording, see section *Performing Data Capture* at page 57 and section *Determining Connection ID* at page 61.



Note: The Connection ID is determined again at every network start-up.

6.3.1 Preparing Time Measurement

In this example the times of the frame sequence from the cifX card (Master) to the NXIO board Slave 3 and return are to be measured.

It is possible to analyze both signal directions in one common measurement.

- The MAC address of the cifX card must be determined.
If the MAC address is not known, it can be determined as follows: Link the PC Ethernet network connection with the Ethernet connection of the cifX card. Start the "Ethernet Device Configuration" with **Start > Programs > SYCON.net System Configurator > Ethernet-device setup**.
Enable the **Search for device** in the main window of the program. You will recognize the cifX card at the **Ethernet/IP Scanner** device type.
- You can determine the MAC addresses of the NXIO Board according to the description within section "EtherNet/IP" of document „*User Manual Real-Time-Ethernet-Kit*“.
- Start the netANALYZER software with **Start > Programs > netANALYZER > netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 57: EtherNet/IP netANALYZER Entry Screen

If you have set up the cabling (as described within section *Hardware Assembly* on page 56) and the communication between the cifX card and the NXIO boards is running, the respective connection status (as displayed at ①) is signed with **UP with data rate** or at elder netANALYZER boards at TAP B only with **UP**.

6.3.2 Adjusting Filter Settings

- Go to the main window of the program using the ③ **Settings > Filter Settings** dialog in the filter settings.
- The filter window appears as follows:




Figure 58: EtherNet/IP netANALYZER Filter cifX → Slave 3

At first select an identical filter for all ports. Here the communication direction cifX to Slave 3 has been selected.

- Select **Filters > Ethernet/IP** ① > **Cyclic frames** ②.
- Copy this filter by clicking **Copy Filter** ③.
- Denominate the filter using a new name (here **Cyclic frames to Slave 3** ④) for the filter.
- Check **Enable Filter A** ⑤.

Target MAC Address

- Fill in the target MAC address into the tagged area (i.e. the MAC address of Slave 3 ⑥).

Source MAC Address

- Fill in the MAC address ⑦ of the cifX card into the tagged area.



Note: For your measurement assembly the MAC addresses have to be adapted to your devices.

Filter Mask

- Fill in „FF“ **8** into the **Mask** fields below source and target address in order to ensure comparing every character within target and source address.
- Select **Accept, if filter A matches** **9**.
- Select this filter for Port 0 by checking option **Select Filters** **10** using the mouse.
- Click **Apply to All Ports** **11** in order to make this filter setting effective at all ports.
- Store the filter settings by clicking **Save Filter** **12**.

Now during a measurement at all ports of the netANALYZER card the cyclic telegrams from the cifX card to Slave 3 are selected. All other telegrams will be filtered, i.e. rejected.

- Leave the filter settings by clicking **OK** **13**.

6.3.2.1 Allocating Port Signal Flow



Note: Because of the Auto crossover functionality of the devices, the Ports 0 and 1 as well as Ports 2 and 3 may be interchanged in your measurement assembly!

- Start the measurement for a short time.
- In the netANALYZER Entry Window you will then get a display similar to the following one:.




Figure 59: EtherNet/IP netANALYZER Direction of Signal Flow

In the red boxes **A** and **B** in line **Frames received OK** below Port 1 and Port 3 you can find out that telegrams from the cifX to Slave 3 have been detected at those ports.

Therefore it can be concluded, that the telegrams from Slave 3 to the cifX card run over Port 2 and Port 0 of the netANALYZER card.



Note: Due to the Auto crossover functionality of the components the signals may run over Port 0 and 2 at your assembly.

For these ports the filters are required to be set accordingly.

6.3.2.2 Createing Filter for Signal Direction from Slave 3 to the cifX

As the slave sends to a broadcast address on its own, we can only work with the MAC source address and a connection ID.

- Proceed from the main window of the program to the filter settings via **Settings > Filter Settings** ③.
- The dialog window for filter settings is opened where you perform the following settings:




Figure 60: EtherNet/IP netANALYZER Filter Slave 3 → cifX

- ① Choose the pane for the desired port (on which no telegrams have been detected up to now), for which you want to create a new filter. (Here it is Port 0, in your application it may be another port.)
- Select **Ethernet/IP** ② > **Cyclic frames** ③.
- Copy the filter by clicking **Copy Filter** ④.
- Assign a new name for the filter. (Here: **Cyclic frames from Slave 3** ⑤.)
- As source address, specify the MAC address of Slave 3 ⑥.

- Enter the identified connection ID **7**. **Caution:** This connection ID must be newly determined after every network start-up
- Fill the mask fields below the MAC target address with „00“ **8**. This prevents them from being checked.
- Fill the mask fields under the MAC source address and the connection ID with „FF“ **9**.
- Check checkbox **Select Filter** **10**.
- Select **Accept, if filter A matches** **11**.
- Store the filter by clicking **Save Filters** **12**.
- Select the second port under **1** at which no telegrams have been detected (here: port 2).
- Select the filter just having been created.
- Check **Select Filter** **11**.
- Check the settings for all ports.
- Leave the filter settings by clicking **OK** **12**.
- Select **Timing Analysis**.
- In the foreground, the window for the graphical display of the timing analysis opens.




Figure 61: netANALYZER Timing Analysis window

The timing analysis window is divided into 4 subwindows consisting of two parts, namely histogram and history. In the further discussion of this measuring set-up usually we concentrate on only one of these 4 subwindows.

The size of the single subwindows can be changed by dragging the point where the window division lines cross.

It is also possible to display only the history window or only the histogram window. You can adjust this in the main window of the netANALYZER under **Settings > Analysis Configuration**.

6.3.3 Settings in the Timing Analysis Windows

At first, take care of **Auto Scale** ① being set.




Figure 62: netANALYZER Timing-Auto-Scale

In this way you ensure, that if telegrams are detected these are also visible as bars and are not outside of the window area.

- Adjust the From / To conditions for each partial window as follows:



Note: At your test setup, the telegrams may run over the respective corresponding port due to the Auto-Crossover feature of the ports of the netANALYZER card. If necessary adapt the ports according to your setup!

6.3.3.1 Settings for Analysis Subwindow A

Here the cycle time for telegrams from the cifX card to slave 3 shall be determined.




Figure 63: EtherNet/IP Port Settings for cycle time, Timing window A

- As the telegrams from the cifX to slave 3 run over port1, you have to set **From** ② and **To** ③ to „Port 1“.
- At ① you can enter a descriptive text for the measurement.
- Take care of the **Auto Scale** ⑤ setting.

6.3.3.2 Settings for Analysis Subwindow B

Here the propagation time of telegrams from the cifX to slave 3 through slaves 1 and 2 are measured.



Figure 64: EtherNet/IP Port Settings for the propagation time from the cifX to slave 3 through slaves 1 and 2, Timing window B

- As the telegrams to slave 3 run over port 1, this port must be set under **From** ②.
- As the signals from slave 3 to the cifX run over **Port 3** this port must be set under **To** ③
- Take care of the „Auto Scale“ setting at ⑤.

6.3.3.3 Settings in Subwindow C

Here the cycle time of input data telegrams into the Ethernet/IP network is measured.



Figure 65: EtherNet/IP Port Settings for Propagation Time to Slave 3, Timing window C

- In this set-up, the telegrams of slave 3 run over port 2. For the cycle time measurement, therefore at **From** (2) and **To** (3) Port 2 has to be set.

6.3.3.4 Settings in Subwindow D

Here the propagation time of telegrams from slave 3 to the cifX through slaves 1 and 2 is measured.



Figure 66: EtherNet/IP Port Settings for the propagation time through Slave 1 and 2 to the cifX, Timing window D

- As the telegrams from slave 3 to the cifX run over Port 2 and 0 at **From Port 2** (2) and at **To Port 0** (3) has to be set.

6.3.4 Performing the Measurements




Figure 67: Main Window of netANALYZER

- Return to the main window of the netANALYZER and start a new measuring cycle by clicking **Start** (1).
- You receive the following results

6.3.4.1 Cycle Time for the Telegram Direction cifX to Slave 3




Figure 68: EtherNet/IP, Cycle Time for Telegram Direction cifX to Slave 3

In figure „A 1“ the histogram and in figure „A 2“ the history of the telegrams can be seen.

If the **From:** and **To:** ports are identical then the cycle time is always measured, Independently of whether the direction is measured from the Master to the Slave or whether the direction is measured from the Slave to the Master.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	99.975 ms
Av Time	The average cycle time of the telegrams	100.000 m s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	100.026 ms
Std. Deviation	The standard deviation of the cycle time	1.826 µs

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of evaluated telegrams	15618
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

6.3.4.2 Propagation Time (through Slave 1 and 2) for Telegrams cifX to Slave 3




Figure 69: EtherNet/IP, Cycle Time for Telegram Direction Slave 3 to cifX

In figure „**B 1**“ the histogram and in figure „**B 2**“ the history of the telegrams can be seen.

Here you can realize, that the maximum propagation time is determined by a few telegrams (3) with very wide distance in time.

Most of the telegrams pass the two slaves here with 15,397 μ s.

At (1) you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	15.330 μ s
Av Time	The average cycle time of the telegrams	15.397 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	15.900 μ s
Std. Deviation	The standard deviation of the cycle time	25 ns

At (2) you can see under:

Denomination	Meaning	Value
Samples	The number of evaluated telegrams	15619
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

6.3.4.3 Cycle Time Slave 3




Figure 70: EtherNet/IP, Cycle Time of Slave 3

In figure „C 1“ the histogram and in figure „C 2“ the history of the telegrams can be seen.

Here, clearly two lower peaks can be identified additionally to the peak of the main cycle. These can be explained as follows.

The slave has a fixed cycle time. If this time is disturbed by random events, the signal will be sent at the network a little later. This reduces the distance to the next sending by the previous time delay. Therefore, a positive and negative time delay is coupled in order to stay within the absolute cycle cycle.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	99.982 ms
Av Time	The average cycle time of the telegrams	100.000 m s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	100.018 ms
Std. Deviation	The standard deviation of the cycle time	6,830 μs

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of evaluated telegrams	15618
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

6.3.4.4 Propagation Time Slave 3 to cifX through Slave 2 and 1




Figure 71: EtherNet/IP, Propagation Time Slave 2 and 1 for Telegram Direction Slave 3 to cifX

In figure „D 1“ the histogram and in figure „D 2“ the history of the telegrams can be seen.

You can realize, that the propagation times of both signal directions slightly differ.

You can also realize, that the maximum propagation time is caused by very few isolated events ③.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	15.234 μ s
Av Time	The average cycle time of the telegrams	15.308 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	15.824 μ s
Std. Deviation	The standard deviation of the cycle time	26 ns

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of evaluated telegrams	15619
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

6.4 Performing Data Capture

The frames of the cifX card to the Slaves and the response frames from the Slaves to the cifX card are to be captured.

Preconditions:

- The hardware assembly as described in section *Hardware Assembly* on page 56 must have been created.
- The configuration for the cifX card must be accomplished (see section 6.4 of the *User manual Real-Time Ethernet Kit - Communication Systems for Real-Time Ethernet Installation, Operation and Configuration*).
- A data exchange between the cifX card and the slaves must have been established.

➤ Start the netANALYZER software with **Start > Programs > netANALYZER > netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 72: netANALYZER Entry Screen

The respective linkage status (as shown for ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 56) has been built up and the communication between the cifX card and the NXIO board is running.

➤ Ensure that in the **Settings > Filter Settings** dialog path (as shown by ②), the filter settings are set as shown in section *Preparing Time Measurement* on page 62. The example further below refers to the filter settings of this hardware assembly from section *Hardware Assembly* on page 56.

- Leave the filter settings using **OK**.
- You are returned to the main window.




Figure 73: Start Data Capture

- Ensure that **Capture data** 4 is turned on.
- Start the capture with a click **Start** 5.
- The **Start** 5 button becomes the **Stop** 5 button.
- Wait until a sufficient number of frames have been captured.
- Click **Stop** 5.
- Click **Convert** 6.
- The following window appears:




Figure 74: pcap Conversion 1

The pcap conversion window consists of 2 columns:

Window Area A

User Interface Element	Description
Path 1	Path to be defined by the user from which the netANALYZER shall read the binary file (*.hea) for conversion. The settings, which are done here, have an effect to the next capture. The settings done at Settings > File Settings are changed with it.
Button 2	Selection button for the selection of the source directory of the .hea files.
All filtered .hea files for this name or capture C	List of .hea files in the selected directory.

Window Area B

User Interface Element	Description
Path 3	Path to be defined by the user where the netANALYZER software shall store the converted WinPcap file (*.pcap)
Button 4	Selection button for the selection of the target directory for storing the .pcap files
File name 5	Systematic file denomination for the .pcap files. The netANALYZER software additionally appends a running number for each file within the filename.
.pcap files that will be generated D	<p>Preview of generated .pcap files The name structure is as follows:</p> <div style="display: flex; align-items: center;"> <div style="flex: 1;"> </div> <div style="flex: 1; padding-left: 10px;"> <p>13 File name from 5.</p> <p>14 consecutive number.</p> <p>15 Time information, consists of yyyymmddhhmmss (start of the capture of the file, if check 6 is set).</p> </div> </div>
Append date/time to pcap file name 6	If checked, date and time are added within the file name
Include FCS in .pcap-files 7	<p>Checkbox whether the Ethernet checksum shall be included within the PCAP file or not (Some Wireshark dissectors do not support FCS.)</p> <p>Note: If Convert to extended .pcap file including additional frame information is checked, Include FCS in .pcap-file is grayed out as FCS is always converted into a .pcap file then. FCS = Frame Check Sequence (Ethernet checksum)</p> <p>Not selectable, if option 10 is checked, however active.</p>
Include corrupted frames in .pcap file 8	If this option is activated, then also erroneous frames will be included into the .pcap file. If it is deactivated, only correct telegrams will be stored in the .pcap file.
Append netANALYZER information block (for Wireshark versions before 1.7.1 with additional plug in only) 9	<p>This option requires the installation of the netANALYZER Wireshark plug-in for Wireshark versions < V1.7.1.</p> <p>Adds the netANALYZER info block to the .pcap file after the Ethernet frame. This supplies additional information for each single telegram such as time of receipt, receiving port or error information.</p> <p>Note: The .pcap file format with info block after the Ethernet frame is no longer supported by Wireshark versions ≥ 1.7.1.</p> <p>Not selectable if option 10 is checked.</p>
Convert to extended .pcap file including additional frame information 10	<p>Note: If this item is checked, the extended .pcap file format generated by the netANALYZER software V1.4.x.x can only be opened in Wireshark versions beginning with V1.7.1.</p> <p>Beginning with netANALYZER software V1.4.x.x an extended .pcap file format can be generated. There the netANALYZER info block is stored in the 4 bytes prior to the Ethernet frame. Therefore, additional information for each single telegram such as time of receipt, receiving port or error information is available.</p>
Convert 11	Conversion of binary files into the WinPcap format is started.
Close 12	The window is closed without starting any conversion.

- Select the file to be converted in window area A.
- Add the necessary settings in window area B.
- Click **Convert 11** in order to convert the data into the .pcap file format.
- Open the file with Wireshark.
- The following data will be displayed.

- Double click on the converted file (here `c:\Default_001.pcap`), or start the Wireshark program and select **File > Open**.
- The Wireshark program displays the data as follows:




Figure 75: EtherNet/IP netANALYZER Wireshark Telegram Display

- ① This window area shows a list of every frame which was captured at every port according to the filter.
- ② In this window area you can see individual frame regions of the selected frame.
- ③ In this window area the data of the selected frame is shown at the Byte level.
- ④ Here a complete frame cycle of the measurement assembly is highlighted. The first row (No 9) contains the frame as it comes from the Master. This was captured at Port 0.
The second row (No 10) contains the frame after its journey through Slave 1 and Slave 2 from the Master to Slave 3.
The third row (No 11) contains the frame as it returns from Slave 3 before continuing to Slave 2.
The fourth row (No 12) contains the frame as it returns from Slave 3 to the Master after passing through Slaves 2 and 3.
- ⑤ Here the part of the frame (first row of the cycle) is highlighted that contains the nominal values for the Slave.
- ⑥ Here the part of the frame (first row of the cycle) is highlighted that contains the nominal values for the Slave 3.

6.5 Preparing and Performing a Network Load Analysis

The network load between slave 2 and slave 3 during start-up of the network configuration shall be determined and the load by a “ping” call shall be demonstrated.

6.5.1 Preparing Network Load Analysis

As described in section *Performing Data Capture* on page 74, you can perform a data capture for the start-up of the network configuration to determine the relevant data for the settings, or you can use predefined filters.

Here, we use the predefined filter settings.

6.5.2 Adjusting Filter Settings

- Switch off hardware filters




Figure 76: Switch off Hardware Filters



Note: The selected hardware filters apply additionally to the *Extended Software Filter*. Therefore uncheck either checkbox *Enable Filter* ① at the hardware filter or uncheck checkbox *Select Filter* ②.

- Adjust software filter.
- For the configuration of the *Extended Software Filters* proceed as follows:
 1. In the netANALYZER main menu click at menu entry **Settings > Extended Software Filter Settings**.
 - The following configuration window is displayed:




Figure 77: Extended Software Filters

If the window area **A** contains more than displayed in the figure above, then erase the entries by clicking **Clear Tree** **1**.

- Click **Load/Add Tree** **2** in order to select a filter.
- The file manager of the operation system opens with the directory of predefined filters.
- Select the file `EtherNetIP_cyclic_frame.xml`. In this filter all settings for cyclic communication at an Ethernet/IP network system are already present.
- After expanding all subentries, the Extended Software Filter should look like this:




Figure 78: Extended Software Filters for cyclic Ethernet/IP Telegrams

Additionally, the „ping“ calls at the network system shall be filtered. To do so, a further filter needs to be added to the one described above.

- Tag the entry start ① according to the figure above, to create an OR relation to the filter already being selected.
- Click **Load/Add Tree** ② to select a further filter.
- The file manager of the operating system opens with a the directory of the predefined filters
- Select the file `ICMP_frame.xml`. In this file, also the settings for a call of “ping” are contained.
- The Extended Software Filter should now look like this after expanding all subentries:




Figure 79: Extended Software Filters for cyclic Ethernet/IP Telegrams and Ping

For each entry tagged with **Identity as** a new named counter is opened for the analysis. As the name **Identity as Ethernet/IP cyclic frame** ① appears four times, all these filter events will be counted into the same named counter. This also applies for the counter **Identity as ICMP frame** ② (for the „Ping“ calls) which has two sources.



Note: If other data sets not matching the filter conditions appear in the telegram analysis, the counter „Other“ will automatically be added to the analysis.

- Store the filter settings for later use. By clicking **OK** ③ you leave the filter window.
- You return to the netANALYZER main window.




Figure 80: netANALYZER Main Window Ethernet/IP Netload Analysis

- Check the checkbox at TAP B for Port 0 and Port 1 **②**. This is necessary as it is not predictable over which port the communication will start due to the auto crossover feature of the Ethernet ports.
- If necessary, uncheck the checkboxes at TAP A **②**.

6.5.3 Performing the Netload Analysis

- For performing the Netload analysis, select “Netload Analysis” in combo box **③**.
- The **Netload Analysis** window opens.
- In order to evaluate also the frames not originating from Ethernet/IP during connection establishment, open the Ethernet connection at CH 0 of slave 1 in Figure 52 to be able to close it again after starting the recording of the analysis.
- Select the main window of the netANALYZER.
- Here, click **Start**.
- The recording of analysis data begins.
- Reconnect the cable at CH 0 of the slave.
- After some time, stop recording by clicking **Stop** in the main window of the netANALYZER.
- In the Netload Analysis window you can see information similar to the following:




Figure 81: Netload Analysis for Ethernet/IP Telegrams (Start-up Phase) and Ping

In the figure above it can be seen, that after a network interruption at the beginning of communication some non-Ethernet/IP telegrams are recorded (Curve ③) and the Ethernet/IP communication (Curve ①) starts approximately 5 seconds after the end of the interruption.

The „pings“ were invoked at CH 1 of slave 3 and were addressed to slave 1. The „ping“ call was repeated twenty times (Curve ②).

If the Ethernet/IP communication is not restarted by the network interruption, but by a power return of the slaves, the non Ethernet/IP communication will even increase in volume as in this case there is the additional communication for the address assignment via DHCP Server. This case is displayed in the next figure.




Figure 82: Netload Analysis for Ethernet/IP Telegrams (Start-up Phase after Power Return)

In the figure above, the non Ethernet/IP telegrams in time frame mostly result ① from the address assignment of the slaves over the DHCP Server and the test on identical addresses at the network. The start of the Ethernet/IP communication occurs about 16 seconds after power return. If more participants are at the network, this time will even increase.

7 SERCOS III Analysis

The following timing parameters are to be measured here as an example:

- measuring the ring propagation times of the primary ring,
- measuring the *ConClk* cycle time at Slave 1,
- measuring cycle time of Master Data Telegram at the output of the master,
- measuring cycle time of Master Data Telegram after passing through 3 slaves.

7.1 Hardware Assembly

The following hardware assembly is required for this measurement example.




Figure 83: sercos Analysis, Hardware Assembly

In the example above, besides the Ethernet linkage, a 2-pole wire 1 is to be inserted between the *ConClk* connection (GND Pin 1 and *ConClk* Pin 9) from Slave 1 to the GPIO connection 0 of the netANALYZER board.



Note: The settings for the cifX card and the NXIO 50 boards must be accomplished in accordance with section 6.5 of the installation, operation and hardware description of this Kit.

7.2 Preparing and Performing the Time Measurement



Note: The cifX card and the NXIO boards offer auto crossover functionality. For this reason an interchange of the cable at the netANALYZER at TAP A (Port 0 and Port 1) as well as at TAP B (Port 2 and Port 3) is without meaning. Thus, also with the display of the analysis values of the Port designation 0/1 or 2/3 can be seen as interchangeable.



Note: Only the settings of the netANALYZER immediately required for this measurement assembly are described here. Detailed information on the setting and capture possibilities of the software can be found in the *User Manual netANALYZER NANL-C500-RE*.

7.2.1 Preparing Time Measurement

The ring propagation time of the primary ring and the *ConClk* cycle time at Slave 1 are to be measured.

- Start the netANALYZER software with **Start > Programs > Hilscher > netANALYZER > netANALYZER**.
- The main window of the netANALYZER opens.




Figure 84: SERCOS III netANALYZER Entry Screen

The respective linkage status (as shown by ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* page 84) has been built up and the communication between the cifX card and the NXIO board is running then. In line ② you can find out, that no filter is currently active.

7.2.2 Adjusting Filter Settings

- Select **Settings > Filter Settings** ③.
- The filter settings window opens.




Figure 85: SERCOS III netANALYZER SERCOS III Filter Settings

For adjusting the filter settings, proceed as follows:

- Select the filter **Filter > SerCOS III > CP4 Frames** ① out of the predefined filters.
- Copy this filter by clicking **Copy Filter** ②.
- Denominate the copied filter, here the name **Ring ConClk** ③ is used.
- Adjust the settings according to the rectangular boxes in the illustration above!

where:

Multicast address ⑩, SERCOS III protocol ⑪, MDT0 primary ⑫, CP4 ⑬.

- Store the filter settings by clicking **Save** ④.
- Select the filter for this port by clicking at the box **Select Filter** ⑤.
- Click **Apply to All Ports** ⑥ in order to make this filter setting effective at all ports.
- Leave the dialog with **OK** ⑦.
- The main window of the netANALYZER opens.
- Adjust the following settings in the **Settings > GPIO Settings** dialog.




Figure 86: SERCOS III netANALYZER GPIO Settings

- Set the GPIO 0 to **rising edge** **20**.
- Leave the dialog with **OK** **21**.
- The main window of the netANALYZER opens.
- Select **Timing Analysis** **2**.
- The window for graphic representation of the Timing Analysis opens in the foreground:



Figure 87: netANALYZER Timing Analysis window

The timing analysis window is divided into 4 subwindows consisting of two parts, namely histogram and history. In the further discussion of this measuring set-up usually we concentrate on only one of these 4 subwindows.

The size of the single subwindows can be changed by dragging the point where the window division lines cross.

It is also possible to display only the history window or only the histogram window. You can adjust this in the main window of the netANALYZER under **Settings > Analysis Configuration**.

7.2.3 Settings in the Timing Analysis Windows

At first, take care of **Auto Scale** ① being set.




Figure 88: netANALYZER Timing-Auto-Scale

In this way you ensure, that if telegrams are detected these are also visible as bars and are not outside of the window area.

➤ Adjust the From / To conditions for each partial window as follows:



Note: At your test setup, the telegrams may run over the respective corresponding port due to the Auto-Crossover feature of the ports of the netANALYZER card. If necessary adapt the ports according to your setup!

7.2.3.1 Settings for Analysis Subwindow A

Here, the propagation time of the telegrams through the ring shall be measured.

➤ For a short time start the timing analysis. Under TAP A and TAP B each a port will be filled with telegrams.

➤ The following picture resulted:




Figure 89: netANALYZER Port-Selection

Here it is obvious, that the telegrams at port 1 come from the cifX and return over port 2 to the cifX.

➤ Adjust the following settings in window A in order to measure the ring-pass through time:



Figure 90: Sercos Settings Timing Analysis Window A

➤ In this row you can enter a name for the measurement ①.

➤ In **From:** select **Port 1** ②.

- In **To:** select **Port 2** ③.

With this setting the cycle time of the telegrams (selected by filter) from the master to the slave.

- Here, the scaling of the X axis ④ (Number of telegrams) in subwindow „A 1“ (Histogram) can be switched between linear and logarithmic scaling and vice versa.
- Take care of **Auto Scale** ⑤ being switched on. This causes the measurement result always to be displayed within the visible part of the window.

7.2.3.2 Settings for Analysis Subwindow B

Measurement of ConClk cycle time at slave 1



Figure 91: Sercos Settings Timing Analysis Window B

- In **From:** select **GPIO 0** ②.
- In **To:** select **GPIO 0** ③.

This setting is used to measure the *ConClk* cycle at Slave 1.

- Take care of **Auto Scale** ⑤ being switched on for the time scale.

7.2.3.3 Settings for Analysis Subwindow C

Measurement of the cycle time of the master data telegram at the output of the master.




Figure 92: Sercos Settings Timing Analysis Window C

- In **From:** select **Port 1** ②.
- In **To:** select **Port 1** ③.

Using this setting, the cycle time of the master data telegram at the output of the master is measured.

- Take care of **Auto Scale** ⑤ being switched on for the time scale.

7.2.3.4 Settings for Analysis Subwindow D

Measurement of the cycle time of the master data telegram after passing through 3 slaves.




Figure 93: Sercos Settings Timing Analysis Window D

- In **From:** select **Port 2** (2).
- In **To:** select **Port 2** (3).

Using this setting, the cycle time of the master data telegram after passing through 3 slaves is measured.

- Take care of **Auto Scale** (5) being switched on for the time scale.

7.2.4 Performing the Measurements

- Click into the main window of the netANALYZER.




Figure 94: netANALYZER Start Analysis Cycle

- Click **Reset** (1). This deletes the previously displayed time data.
- Click **Start** (2) to start the analysis.
- The former Start button now becomes the Stop button.
- Wait as long as you want to evaluate telegrams.
- Wait for the time in which you would like to evaluate frames.
- Click **Stop**.

7.2.4.1 Timing Analysis Window A: Ring Propagation Time

➤ You will now find the following information in the window A of the Timing Analysis window:




Figure 95: SERCOS III netANALYZER Ring Delay Time

In figure „**A 1**“ (the histogram), the distribution and number of telegrams is displayed in dependence of the time.

In the history window „**A 2**“, the distribution of the telegrams is displayed in dependence of the time.

At **1** you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	1.764 μ s
Av Time	The average cycle time of the telegrams	1.832 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	1.894 μ s
Std. Deviation	The standard deviation of the cycle time	20 ns

At **2** you can see under:

Denomination	Meaning	Value
Samples	The number of analyzed frames.	210389
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

7.2.4.2 Timing Analysis Window B: ConClk Cycle Time Slave 1

➤ You will now find the following information in the window B of the Timing Analysis window:

Remark: The ConClk time depends from the cycle time adjusted at the network master. The cycle time has been set to 2 ms.




Figure 96: netANALYZER ConClk Cycle Time at Slave 1

In figure „B 1“ (the histogram), the distribution and number of telegrams is displayed in dependence of the time.

In the history window „B 2“, the distribution of the telegrams is displayed in dependence of the time.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	2.000 ms
Av Time	The average cycle time of the telegrams	2.000 ms
Max Time	The maximum cycle time and the percental deviation to the average propagation time	2.000 ms
Std. Deviation	The standard deviation of the cycle time	35 ns

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of analyzed frames.	210388
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

It is obvious, that there are no periodic changes of the signal within the time.

7.2.4.3 Timing Analysis Window C: Cycle Time of the Master Data Telegram at the Output of the Master




Figure 97: Cycle Time Master Data Telegram Output Master

In figure „C 1“ (the histogram), the distribution and number of telegrams is displayed in dependence of the time.

In the history window „C 2“, the distribution of the telegrams is displayed in dependence of the time.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	2.000 080 ms
Av Time	The average cycle time of the telegrams	2.000 153ms
Max Time	The maximum cycle time and the percental deviation to the average propagation time	2.000 210ms
Std. Deviation	The standard deviation of the cycle time	22 ns

The absolute jitter time amounts 130 ns.

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of analyzed frames.	210388
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

7.2.4.4 Timing Analysis Window D: Cycle Time of the Master Data Telegram after passing through 3 Slaves

One expects, that the jitter of the master data telegram is increased after passing through 3 slaves (due to their processing).




Figure 98: Cycle Time Master Data Telegram after passing through 3 Slaves

In figure „D 1“ (the histogram), the distribution and number of telegrams is displayed in dependence of the time.

In the history window „D 2“, the distribution of the telegrams is displayed in dependence of the time.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	2.000 050ms
Av Time	The average cycle time of the telegrams	2.000 153ms
Max Time	The maximum cycle time and the percental deviation to the average propagation time	2.000 290ms
Std. Deviation	The standard deviation of the cycle time	33 ns

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of analyzed frames.	210388
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

7.3 Performing Data Capture

The frames of the cifX card to the Slaves and the response frames from the Slaves to the cifX card are to be captured.

Preconditions:

- The hardware assembly as described in section *Hardware Assembly* on page 84 must have been created,
 - the settings for the cifX card must be carried out,
 - there must be a data exchange between cifX card and the Slaves.
- Start the netANALYZER software with **Start > Programs > Hilscher > netANALYZER**.
- The main window of the netANALYZER opens.




Figure 99: SERCOS III netANALYZER Analysis Start

The respective linkage status (as shown ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 84) has been built up and the communication between the cifX card and the NXIO board is running.

- Ensure that in the **Settings > Filter Settings** ② dialog, the time settings are enabled as described in section *Preparing and Performing the Time Measurement* on page 85.
- You are returned to the main window.




Figure 100: Start Data Capture

- Ensure that **Capture data** ④ is turned on.
- Start the capture with a click **Start** ⑤.
- The **Start** ⑤ button becomes the **Stop** ⑤ button.
- Wait until a sufficient number of frames have been captured.
- Click **Stop** ⑤.
- Click **Convert** ⑥.

➤ The following window appears:





Figure 101: pcap Conversion 1

The pcap conversion window consists of 2 columns:

Window Area A

User Interface Element	Description
Path ①	Path to be defined by the user from which the netANALYZER shall read the binary file (*.hea) for conversion. The settings, which are done here, have an effect to the next capture. The settings done at Settings > File Settings are changed with it.
Button ②	Selection button for the selection of the source directory of the .hea files.
All filtered .hea files for this name or capture ③	List of .hea files in the selected directory.

Window Area B

User Interface Element	Description
Path 3	Path to be defined by the user where the netANALYZER software shall store the converted WinPcap file (*.pcap)
Button 4	Selection button for the selection of the target directory for storing the .pcap files
File name 5	Systematic file denomination for the .pcap files. The netANALYZER software additionally appends a running number for each file within the filename.
.pcap files that will be generated D	<p>Preview of generated .pcap files The name structure is as follows:</p> <div style="display: flex; align-items: center;"> <div style="flex: 1;">  <div style="flex: 1; padding-left: 10px;"> <p>13 File name from 5.</p> <p>14 consecutive number.</p> <p>15 Time information, consists of <code>yyyymmddhhmmss</code> (start of the capture of the file, if check 6 is set).</p> </div> </div> </div>
Append date/time to pcap file name 6	If checked, date and time are added within the file name
Include FCS in .pcap-files 7	<p>Checkbox whether the Ethernet checksum shall be included within the PCAP file or not (Some Wireshark dissectors do not support FCS.)</p> <p>Note: If Convert to extended .pcap file including additional frame information is checked, Include FCS in .pcap-file is grayed out as FCS is always converted into a .pcap file then. FCS = Frame Check Sequence (Ethernet checksum)</p> <p>Not selectable, if option 10 is checked, however active.</p>
Include corrupted frames in .pcap file 8	If this option is activated, then also erroneous frames will be included into the .pcap file. If it is deactivated, only correct telegrams will be stored in the .pcap file.
Append netANALYZER information block (for Wireshark versions before 1.7.1 with additional plug in only) 9	<p>This option requires the installation of the netANALYZER Wireshark plug-in for Wireshark versions < V1.7.1.</p> <p>Adds the netANALYZER info block to the .pcap file after the Ethernet frame. This supplies additional information for each single telegram such as time of receipt, receiving port or error information.</p> <p>Note: The .pcap file format with info block after the Ethernet frame is no longer supported by Wireshark versions ≥ 1.7.1.</p> <p>Not selectable if option 10 is checked.</p>
Convert to extended .pcap file including additional frame information 10	<p>Note: If this item is checked, the extended .pcap file format generated by the netANALYZER software V1.4.x.x can only be opened in Wireshark versions beginning with V1.7.1.</p> <p>Beginning with netANALYZER software V1.4.x.x an extended .pcap file format can be generated. There the netANALYZER info block is stored in the 4 bytes prior to the Ethernet frame. Therefore, additional information for each single telegram such as time of receipt, receiving port or error information is available.</p>
Convert 11	Conversion of binary files into the WinPcap format is started.
Close 12	The window is closed without starting any conversion.

- Select the file to be converted in window area A.
- Add the necessary settings in window area B.
- Click **Convert 11** in order to convert the data into the .pcap file format.
- Open the file with Wireshark.
- The following data will be displayed.

The program Wireshark displays the data as follows:




Figure 102: SERCOS III netANALYZER Wireshark Telegram Display

① This window area shows a list of every frame which was detected according to the filter. At ④ it can be seen at which Port of the netANALYZER the frame has arrived.



Note: If in the window area ① the **event on GPIO...** is missing, then the Hilscher Wireshark Dissector has not been enabled. Enable it according to the *netANALYZER user manual Rev. 8* (section 14.4).

② In this window area you can see individual frame area of the selected frame. At ⑤ it can be seen at which Port of the netANALYZER board the frame has arrived.

Caution!

In order to receive the commented-upon representation (in the window area ②) it may be necessary to download another plug-in from the SERCOS home page "<https://www.sercos.org>" for the Wireshark program.

③ In this window area the data of the selected frame is shown at the Byte level.

8 Modbus/TCP Analysis

The following timing parameters are to be measured here as an example:

- measuring the reaction time from Slave 3,
- measuring the propagation time of the frames from Slave 3 through Slaves 1 and 2,
- measuring the cycle time of the cifX telegrams,
- measuring the network load with Modbus/TCP telegrams at network start-up and at “ping”.

8.1 Hardware Assembly

The following hardware assembly is to be carried out for this measurement example.




Figure 103: Modbus/TCP Analysis, Hardware Assembly

The MAC addresses applicable for the assembly are listed above the components.

Ensure that the respective MAC address is unique in the world. For this reason the devices in your measurement assembly have different MAC addresses.



Note: The settings for the NXIO 50 boards must be accomplished in accordance with section 6.6 of the *User manual Real-Time Ethernet Kit - Communication Systems for Real-Time Ethernet Installation, Operation and Configuration*.



Note: Ensure that the PC is not connected to the in-house network during the measurement or is uncoupled by means of a switch at the least. Otherwise incorrect measurements can occur.

8.2 Preparing and Performing the Time Measurement



Note: The NXIO boards offers auto crossover functionality. For this reason an interchange of cables at the netANALYZER at TAP A (Port 0 and Port 1) as well as at TAP B (Port 2 and Port 3) has no meaning. In this way also with the display of the analysis values, the Port designations 0/1 and 2/3 can be seen as interchangeable.



Note: Only the immediately required settings for this measurement assembly of the netANALYZER are described here. Detailed information on the settings and capture possibilities of the software can be found in the *User Manual netANALYZER NANL-C500-RE* documentation.

8.2.1 Preparing Time Measurement

➤ Start the netANALYZER software with **Start > Program Files> Hilscher GmbH > Hilscher netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 104: Modbus/TCP netANALYZER Entry Screen

The respective linkage status (as shown by ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 99) has been built up and the communication between the cifX card and the NXIO boards is running.

At ② you can find out whether a filter is set (ACTIVE). If this is case, check whether the filter settings for the current measurement assembly are correct.

Due to the auto crossover functionality of the ports at first it is necessary to examine over which ports the communication cifX > Slave 3 runs. For this purpose, certain filter settings are required.

- From the main window select **Settings > Filter Settings** ③.
- The filter window appears as follows.

8.2.2 Adjusting Filter Settings

1. At first, you must determine over which ports the communication takes place into which direction. Therefore at first a filter for the telegrams from cifX to slave 3 is defined.




Figure 105: Modbus/TCP netANALYZER Filter 1

- Adjust the filter settings according to the figure above:
- Choose one port ① for which you want to adjust the settings. At first, this selection is not important, because in the first step the filter has to be adjusted identically for all ports.
- Select **Filters > Modbus/TCP** ② > **Modbus/TCP frames** ③.
- Copy this filter by clicking **Copy Filter** ④.
- Denominate the filter using a new name (here Modbus/TCP frames S3 ⑤).

- Fill in the target MAC address **⑥** into the area tagged in red. Here the MAC address of Slave 3 is required.
 - Fill in the source MAC address **⑦** of the telegrams into the area tagged in green.
 - Fill in „FF“ **⑧** into the **Mask** fields in order to ensure comparing with exactly the specified values.
 - Overwrite the existing entries in both tagged areas with „00“ **⑨**.
 - Store the filter settings by clicking **Save Filter** **⑩**.
 - Select the filter created just now for the chosen port **⑪**.
 - Click **Apply to All Ports** **⑫** in order to make the filter settings valid for all ports.
 - Check whether **Accept, if filter A matches** **⑬** is selected.
 - Leave the filter settings by clicking **OK** **⑭**.
- You are returned to the main window of the netANALYZER:




Figure 106: Modbus/TCP netANALYZER Filter 1 Test

- Start the timing analysis only for a short time by clicking **Start** **①** and subsequently **Stop** (the same button).
- Now you can see in the picture above that telegrams were counted in the column **Frames received OK** below port 1 and port 3. You can assume that these telegrams ran from the cifX (Client) to slave 3 via port 1 and port 3.



Note: Due to the Auto crossover functionality of the devices, the Ports of the netANALYZER card in your measurement assembly may also run via ports 0 and 2. In this case, adapt the following settings!

2. Now, a filter for the reply of slave 3 to the cifX card needs to be created.

- Again proceed to the filter settings via **Settings > Filter Settings** ③.
- Copy the filter which you already created in order to create a new filter for the signal direction from slave 3 to client (cifX card). Proceed as follows:




Figure 107: Modbus/TCP netANALYZER Filter 2

- Select a port which did not detect any telegrams during the preceding signal capturing. Here it is port 0 ①.
- Select the previously defined filter **Modbus/TCP frames S3** ②.
- Click **Copy Filter** ③ in order to copy the filter.
- Denominate the copied filter using a new name, here **Modbus/TCP frames S3R** ④ for the filter.
- Fill in the target MAC address of the telegrams from slave 3 to the cifX (Client) into the tagged area ⑤.
- Fill in the source MAC address of slave 3 into the tagged area ⑥.
- Fill in „FF“ into the mask field ⑦ in order to ensure exact comparison of the specified values.
- Store the filter settings by clicking **Save Filter** ⑧.
- Select this newly stored filter for the current port (here port 0 ⑨).
- Select the port which did not have selected any telegrams (here this is port 2 ⑩). Click at the newly created filter ④ in order to select it.
- Click ⑨ in order to activate the filter for this port.

Change to the filter **Modbus/TCP frames S3**.

Here you select onto the telegrams with function code FC 4.




Figure 108: Modbus/TCP netANALYZER Filter 3

Proceed as follows:

- Fill in the value 04 for function code FC 4 at filter position 11 (Line 0x038, Column 0x5). Then add the mask entry „FF“ in the line below.
- Store this change by clicking **Save Filter** 12.
- Leave the filter dialog by clicking **OK** 13.
- You are returned to the main window.




Figure 109: Modbus/TCP netANALYZER Start Timing Analysis

- Select **Timing Analysis** ①.
- In the foreground the window for graphic representation of the Timing Analysis opens:



Figure 110: netANALYZER Timing Analysis window

The timing analysis window is divided into 4 subwindows consisting of two parts, namely histogram and history. In the further discussion of this

measuring set-up usually we concentrate on only one of these 4 subwindows.

The size of the single subwindows can be changed by dragging the point where the window division lines cross.

It is also possible to display only the history window or only the histogram window. You can adjust this in the main window of the netANALYZER under **Settings > Analysis Configuration**.

8.2.3 Settings in the Timing Analysis Windows

At first, take care of **Auto Scale** ① being set.




Figure 111: netANALYZER Timing-Auto-Scale

In this way you ensure, that if telegrams are detected these are also visible as bars and are not outside of the window area.

➤ Adjust the From / To conditions for each partial window as follows:



Note: At your test setup, the telegrams may run over the respective corresponding port due to the Auto-Crossover feature of the ports of the netANALYZER card. If necessary adapt the ports according to your setup!

8.2.3.1 Settings for Analysis Subwindow A: Telegram Propagation Time

Here, the telegram propagation time (of the telegrams from the cifX to slave 3) through slave 1 and 2 shall be determined.




Figure 112: Modbus/TCP netANALYZER Measuring Window Settings 1

In the headline you can put in a descriptive text for the measurement ①.

From: port of measurement (here Port 1 ②), the port at which the telegrams are received from the cifX card prior to the first slave.

To: port of measurement (here Port 3 ③), the port at which the telegrams arrive at the netANALYZER- card after running through slave 1 and 2.

Take care of **Auto Scale** ⑤ being switched on ensuring that the measuring results are always visible within the display window.

8.2.3.2 Settings for Analysis Subwindow B: Response Time

Here the response time of slave 3 shall be measured.




Figure 113: Modbus/TCP netANALYZER Start / Stop Window B

In the headline you can put in a descriptive text for the measurement ①.

From: port of measurement (here Port 3 ^②), the port at which the telegrams arrive at slave 3.

To: port of measurement (here Port 2 ^③), the port at which the response telegrams arrive from slave 3.

Take care of **Auto Scale** ^⑤ being switched on ensuring that the measuring results are always visible within the display window.

8.2.3.3 Settings for Analysis Subwindow C: Telegram Propagation Time

Here, the telegram propagation time (of the telegrams from slave 3 to the cifX) through slave 1 and 2 shall be determined.




Figure 114: Modbus/TCP netANALYZER Start / Stop Window C

In the headline you can put in a descriptive text for the measurement ^①.

From: port of measurement (here Port 2 ^②), the port at which the response telegrams arrive from slave 3

To: port of measurement (here Port 0 ^③), the port at which the response telegrams arrive from slave 3 after running through slave 2 and 1

Take care of **Auto Scale** ^⑤ being switched on ensuring that the measuring results are always visible within the display window.

8.2.3.4 Settings for Analysis Subwindow D: Cycle Time

Here the cycle time of the telegrams from the cifX shall be measured.



Figure 115: Modbus/TCP netANALYZER Start / Stop Window D

In the headline you can put in a descriptive text for the measurement ^①.

From: port of measurement (here Port 1 ^②), the port at which the telegrams arrive from the cifX card.

To: port of measurement (here Port 1 ^③), the start port and stop port are identical in this case in order to be able to measure the cycle time of the telegrams.

Take care of **Auto Scale** ^⑤ being switched on. This causes the measuring results always to be visible within the display window.

8.2.4 Performing the Measurements

- Click the main window of the netANALYZER.




Figure 116: netANALYZER main window

- Click **Reset** (1). This deletes the previously captured time data.
- Click **Start** (2) to start the analysis.
- The **Start** button becomes the **Stop** button.
- Wait for the time during which you would like to evaluate the frames.



Note: If you want to view single partial areas during the running analysis, switch the window **Auto Scale** off.

- Click **Stop**.
- In the windows you will find the following information now:

8.2.4.1 In Subwindow A: Telegram Propagation Time

Here you can see the propagation time of the FC 4 telegrams to the slave (Server) 3 through slave 1 and slave 2.




Figure 117: Modbus/TCP netANALYZER Analysis Window A

In figure „**A 1**“ (the histogram), the distribution and number of telegrams is displayed in dependence of the time.

In the history window „**A 2**“, the distribution of the telegrams is displayed in dependence of the time.

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	15.918 μ s
Av Time	The average cycle time of the telegrams	16.008 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	16.098 μ s
Std. Deviation	The standard deviation of the cycle time	31 ns

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of analyzed frames.	2319
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

8.2.4.2 In Subwindow B: Response Time

Here you can see the response time to the FC 4 telegrams of the cifX card to the slave (Server) 3




Figure 118: Modbus/TCP netANALYZER Analysis Window B

In figure „B 1“ (the histogram), the distribution and number of telegrams is displayed in dependence of the time.

In the history window „B 2“, the distribution of the telegrams is displayed in dependence of the time.

If the analysis runs over a longer time, a drift of the response time can be observed in the history window „B 2“.




Figure 119: Modbus/TCP netANALYZER Analysis Window B

8.2.4.3 In Subwindow C: Response Telegram Propagation Time

➤ You will now find the following information in sub window C of the Timing Analysis window.




Figure 120: Modbus/TCP netANALYZER Analysis Window C

Here you can see the propagation time of the response telegrams to the FC 4 telegrams of the cifX card to the slave (Server) 3 through slave 1 and slave 2.

It is obvious to see, that there are two maxima in the distribution of the propagation time, which however are constant with regard to the time.

Ahead of the measurement picture the following statistical values are displayed:

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	15.752 μ s
Av Time	The average cycle time of the telegrams	15.929 μ s
Max Time	The maximum cycle time and the percental deviation to the average propagation time	16.112 μ s
Std. Deviation	The standard deviation of the cycle time	85 ns

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of analyzed frames.	5054
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

8.2.4.4 In Subwindow D: Cycle Time

➤ You will now find the following information in sub window D of the Timing Analysis window.




Figure 121: Modbus/TCP netANALYZER Analysis Window D

Here you can see the cycle time with which the FC 4 telegrams of the cifX card are sent to the slave (Server) 3.

In window „D 2“ it can be observed, that the distribution of the cycle time over the time is constant.

Ahead of the measurement picture the following statistical values are displayed:

At ① you can see under:

Denomination	Meaning	Value
Min Time	The minimum cycle time and the percental deviation to the average cycle time	11.976 ms
Av Time	The average cycle time of the telegrams	12.000 ms
Max Time	The maximum cycle time and the percental deviation to the average propagation time	12.023 ms
Std. Deviation	The standard deviation of the cycle time	9,068 µs

At ② you can see under:

Denomination	Meaning	Value
Samples	The number of analyzed frames.	2526
Below Range	The number of telegrams below the displayed time period (Y axis).	0
Over Range	The number of telegrams above the displayed time period (Y axis).	0

8.3 Performing Data Capture

It is desired to show the frames of the PC Ethernet board to Slave 3 and the response frames from Slave 3 to the Ethernet board.

Preconditions:

- The hardware assembly as described in section Hardware Assembly on page 99 must be created,
- the Modbus Master software must be started and linked with Slave 3.



Note: At the recording of telegrams only the settings of the hardware filters are active.

- Start the netANALYZER software with **Start > Programs > netANALYZER > netANALYZER**.

➤ The main window of the netANALYZER opens.




Figure 122: Modbus/TCP netANALYZER Analysis Start

The respective linkage status (as shown by ①) is marked **UP** when the cabling (as described in section *Hardware Assembly* on page 99) has been built up and the communication between the cifX card and the NXIO board is running then.

- Ensure that in the **Settings > Filter Settings** dialog path (as shown by ②), the filter settings are set as described in section *Preparing Time Measurement* on page 100.
- Leave the filter settings using **OK**.
- You are returned to the main window.




Figure 123: Start Data Capture

- Ensure that **Capture data** ④ is turned on.
- Start the capture with a click **Start** ⑤.
- The **Start** ⑤ button becomes the **Stop** ⑤ button.
- Wait until a sufficient number of frames have been captured.
- Click **Stop** ⑤.
- Click **Convert** ⑥.

The following window appears:





Figure 124: pcap Conversion 1

The pcap conversion window consists of 2 columns:

Window Area A

User Interface Element	Description
Path 1	Path to be defined by the user from which the netANALYZER shall read the binary file (*.hea) for conversion. The settings, which are done here, have an effect to the next capture. The settings done at Settings > File Settings are changed with it.
Button 2	Selection button for the selection of the source directory of the .hea files.
All filtered .hea files for this name or capture C	List of .hea files in the selected directory.

Window Area B

User Interface Element	Description
Path 3	Path to be defined by the user where the netANALYZER software shall store the converted WinPcap file (*.pcap)
Button 4	Selection button for the selection of the target directory for storing the .pcap files
File name 5	Systematic file denomination for the .pcap files. The netANALYZER software additionally appends a running number for each file within the filename.
.pcap files that will be generated D	<p>Preview of generated .pcap files The name structure is as follows:</p> <div style="display: flex; align-items: center;"> <div style="flex: 1;">  </div> <div style="flex: 1; padding-left: 10px;"> <p>13 File name from 5.</p> <p>14 consecutive number.</p> <p>15 Time information, consists of <code>yyyymmddhhmmss</code> (start of the capture of the file, if check 6 is set).</p> </div> </div>
Append date/time to pcap file name 6	If checked, date and time are added within the file name
Include FCS in .pcap-files 7	<p>Checkbox whether the Ethernet checksum shall be included within the PCAP file or not (Some Wireshark dissectors do not support FCS.)</p> <p>Note: If Convert to extended .pcap file including additional frame information is checked, Include FCS in .pcap-file is grayed out as FCS is always converted into a .pcap file then. FCS = Frame Check Sequence (Ethernet checksum)</p> <p>Not selectable, if option 10 is checked, however active.</p>
Include corrupted frames in .pcap file 8	If this option is activated, then also erroneous frames will be included into the .pcap file. If it is deactivated, only correct telegrams will be stored in the .pcap file.
Append netANALYZER information block (for Wireshark versions before 1.7.1 with additional plug in only) 9	<p>This option requires the installation of the netANALYZER Wireshark plug-in for Wireshark versions < V1.7.1.</p> <p>Adds the netANALYZER info block to the .pcap file after the Ethernet frame. This supplies additional information for each single telegram such as time of receipt, receiving port or error information.</p> <p>Note: The .pcap file format with info block after the Ethernet frame is no longer supported by Wireshark versions ≥ 1.7.1.</p> <p>Not selectable if option 10 is checked.</p>
Convert to extended .pcap file including additional frame information 10	<p>Note: If this item is checked, the extended .pcap file format generated by the netANALYZER software V1.4.x.x can only be opened in Wireshark versions beginning with V1.7.1.</p> <p>Beginning with netANALYZER software V1.4.x.x an extended .pcap file format can be generated. There the netANALYZER info block is stored in the 4 bytes prior to the Ethernet frame. Therefore, additional information for each single telegram such as time of receipt, receiving port or error information is available.</p>
Convert 11	Conversion of binary files into the WinPcap format is started.
Close 12	The window is closed without starting any conversion.

- Select the file to be converted in window area A.
- Add the necessary settings in window area B.
- Click **Convert 11** in order to convert the data into the .pcap file format.
- Open the file with Wireshark.
- The following data will be displayed.

The Wireshark program displays the data as follows:




Figure 125: Modbus/TCP netANALYZER Wireshark Telegram Display

- (A) This window area shows a list of all frames detected in accordance with the filter settings. Here in (2) the Port of the netANALYZER can be found on which the frame was captured.
- (B) In this window area you can see individual frame regions of the selected frame. Here, under (3) the separate Modbus-Telegram parts can be expanded.
- (C) In this window area the data of the selected frame is shown at the Byte level.
- (1) A frame cycle can be seen here. The captured frames are numbered in sequence.

Nr.	Port	Description
25	1	The point in time at which the frame (from the Master to the Slave) left the PC.
26	3	The point in time at which the frame is at the Slave 3. As the telegram contents has already been recorded, the telegram is displayed with black background and tagged with [TCP-Out-of Order].
27	2	The point in time at which the answer frame from the Slave to the Master left the Slave
28	0	The point in time at which the answer of the Slave arrives at the PC.

As recording to 2 TAPs is done and telegrams passing through may be recorded twice, Wireshark is not able to check the order of the TCP segments.

Therefore the segment of a previously recorded telegram is displayed in **black** and marked as [TCP-Out-of Order].

⑤ Here the function code (1) in the frame has been selected and its position at the Byte level can be seen at the number ⑥.

8.4 Preparing and Perform a Network Load Analysis

The network load between slave 2 and slave 3 at start-up of the network communication shall be determined and the load by a „ping“ call shall be demonstrated.

8.4.1 Preparing Network Load Analysis

- As described in section *Performing Data Capture* on page 112 you can perform a data capture for the network start-up to determine the relevant data for the settings, or you can use predefined settings.

Here, we use the predefined filter settings.



Note: During the network load analysis, always the **Extended Software Filter** are active.

8.4.2 Adjusting Filter Settings

- Switch off hardware filters




Figure 126: Switch off Hardware Filters



Note: The selected hardware filters apply additionally to the *Extended Software Filter*. Therefore uncheck either checkbox *Enable Filter* ① at the hardware filter or uncheck checkbox *Select Filter* ②.

- Adjust software filter.
- For the configuration of the *Extended Software Filters* proceed as follows:

1. In the netANALYZER main menu click at menu entry **Settings > Extended Software Filter Settings**.

⇒ The following configuration window is displayed:




Figure 127: Extended Software Filters

If the window area **A** contains more than displayed in the figure above, then erase the entries by clicking **Clear Tree** **1**.

- Click **Load/Add Tree** **2** in order to select a filter.

⇒ The file manager of the operation system opens with the directory of predefined filters.

- Select the file `MODBUS_frame.xml`. In this filter all settings for cyclic communication at an Modbus/TCP network system are already present.

After expanding all subentries, the Extended Software Filter should look like this:




Figure 128: Extended Software Filters for cyclic Modbus/TCP Telegrams

Additionally, the „ping“ calls at the network system shall be filtered. To do so, a further filter needs to be added to the one described above.

- Tag the entry **Start** ① according to the figure above to create an OR relation to the filter already being selected.
- Click **Load/Add Tree** ② to select a further filter.
- The file manager of the operating system opens with a the directory of the predefined filters
- Select the file `ICMP_frame.xml`. In this file, also the settings for a call of “ping” are contained.

- The Extended Software Filter should now look like this after expanding all subentries:




Figure 129: Extended Software Filters for cyclic MODBUS/TCP Telegrams and Ping

For each entry tagged with **Identify as** a new named counter is opened for the analysis. As the name **Identify as MODBUS/TCP frame** ① appears four times, all these filter events will be counted into the same named counter. This also applies for the counter **Identify as ICMP frame** ② (for the „Ping“ call) which has two sources.



Note: If other data sets not matching the filter conditions appear at the telegram analysis, the counter **Other** will automatically be added to the analysis.

- Store the filter settings for later use. By clicking **OK** ③ you leave the filter window.
- You return to the netANALYZER main window.




Figure 130: netANALYZER Main Window MODBUS/TCP Netload Analysis

- Check the checkbox at TAP B for Port 0 and Port 1 ②.
This is necessary as it is not predictable over which port the communication will start due to the auto crossover feature of the Ethernet ports.
- If necessary, uncheck the checkboxes at TAP A ②.

8.4.3 Performing the Network Load Measurement

- For performing the Netload analysis, select **Netload Analysis** in combo box ③.
- The **Netload Analysis** window opens
- In order to evaluate also the frames not originating from Modbus/IP during connection establishment, open the Ethernet connection at CH 0 of slave 1 in *Figure 103* to be able to close it again after starting the recording of the analysis.
- Select the main window of the netANALYZER.
- Here, click **Start**.
- The recording of analysis data begins.
- Reconnect the cable at CH 0 of the slave.
- After some time, stop recording by clicking **Stop** in the main window of the netANALYZER.
- In the Netload Analysis window you can see information similar to the following:




Figure 131: Network Load for cyclic MODBUS/TCP Telegrams and Ping

In the figure above it can be seen, that after a network interruption at the beginning of communication some non-MODBUS/TCP telegrams are recorded (Curve ②) and the MODBUS/TCP communication (Curve ③) starts approximately 1 second after the end of the interruption.

The „pings“ were invoked at CH 1 of slave 3 and were addressed to slave 1. The „ping“ call was repeated twenty times (Curve ①). The first “ping” call is started with an ARP telegram. Thus, there is a peak at telegram counter **Other**.

If the Modbus/TCP communication is not restarted by the network interruption, but by a power return of the slaves, the non Modbus/TCP communication will even increase in volume as in this case there is the additional communication for the address assignment via DHCP Server. This case is displayed in the next figure.




Figure 132: Netload Analysis for Modbus/TCP Telegrams (Start-up Phase after Power Return)

In the figure above, the non Modbus/TCP telegrams in time frame **A** mostly result from the address assignment of the slaves over the DHCP Server and the test on identical addresses at the network. The start of the cyclic Modbus/TCP communication occurs about 13 seconds after power return. If more participants are at the network, this time will even increase.

If you follow with the mouse pointer along a measurement line in figure **4**, the mouse pointer will change to a hand and the number of telegrams counted per second for this filter is displayed.

9 Glossary

CSV

Comma **S**eparated **V**alue

GPIO

General **P**urpose Input/**O**utput

hea

File ending of the generated binary file (default.hea) of the Hilscher netANALYZER software with the Capture Information content.

.NET Framework Version 2.0

Microsoft .NET Framework Version 2.0

<http://www.microsoft.com/downloads/details.aspx?familyid=0856EACB-4362-4B0D-8EDD-AAB15C5E04F5&displaylang=de>

PIO

Programmable Input/**O**utput

TAP

Test **A**ccess **P**oint

Wireshark

“Wireshark Network monitoring program”

<http://www.wireshark.org>

WinPcap

“The WinPcap” library”

<http://www.winpcap.org/>

10 Appendix

10.1 List of Figures

Figure 1: netANALYZER Main Window	12
Figure 2: netANALYZER File Settings	13
Figure 3: Timing analysis, change scaling	14
Figure 4: Timing Analysis, scaling with the Mouse	15
Figure 5: PROFINET IO Analysis, Hardware Assembly	16
Figure 6: netANALYZER Entry Screen	17
Figure 7: netANALYZER Filter Settings (1)	18
Figure 8: netANALYZER Filter Settings (2)	19
Figure 9: netANALYZER, Selection Timing Analysis	21
Figure 10: netANALYZER Measurement Window	22
Figure 11: netANALYZER Main Window after Measurement Cycle	23
Figure 12: netANALYZER Measurement Window Settings 1	24
Figure 13: netANALYZER Measuring Window Settings 2	24
Figure 14: netANALYZER Main Window Start/Reset	25
Figure 15: netANALYZER PROFINET IO Cycle time Measurement, auto-scale	25
Figure 16: PROFINET IO, Device 1 Propagation time	26
Figure 17: PROFINET IO, Device 1 Propagation Time, History extremely scaled	27
Figure 18: Main Window for Telegram Recording	28
Figure 19: netANALYZER PROFINET IO Filter Settings	29
Figure 20: Start Data Capture	29
Figure 21: pcap Conversion 1	30
Figure 22: PROFINET IO netANALYZER Wireshark Telegram Display	32
Figure 23: Standard PROFINET Data Set	33
Figure 24: Switch off hardware filter	34
Figure 25: Create Extended Software Filter (1)	34
Figure 26: Create Extended Software Filter (2)	35
Figure 27: Extended Software Filter after 1. Entry	35
Figure 28: Extended Software Filter after 2. Entry	36
Figure 29: Extended Software Filter after 3. Entry	37
Figure 30: netANALYZER Main Window PROFINET Netload Analysis	38
Figure 31: Netload Analysis for PROFINET Start-up Phase	39
Figure 32: Extended Software Filter with FrameID	40
Figure 33: Netload Analysis for PROFINET Start-up Phase with FrameID 8002	40
Figure 34: EtherCAT Analysis, Hardware Assembly	41
Figure 35: netANALYZER Entry Screen	42
Figure 36: netANALYZER Filter Window	43
Figure 37: netANALYZER Timing Analysis window	44
Figure 38: netANALYZER Timing-Auto-Scale	44
Figure 39: Timing Analysis Window A, EtherCAT Cycle Time	45
Figure 40: Timing Analysis Window B, EtherCAT Ring Propagation Time (1)	45
Figure 41: Timing Analysis Window C, EtherCAT Ring Propagation Time (2)	45
Figure 42: Timing Analysis Window, EtherCAT Ring Propagation Time (2)	46
Figure 43: netANALYZER Start/Stop Analysis	46
Figure 44: EtherCAT Timing Analysis Window A with measured Data	47
Figure 45: EtherCAT Timing Analysis Window B with measured Data	48
Figure 46: EtherCAT Timing Analysis Window C with measured Data	50
Figure 47: EtherCAT Timing Analysis Window D with measured Data	51
Figure 48: EtherCAT netANALYZER Main Window	52
Figure 49: Start Data Capture	53
Figure 50: pcap Conversion 1	53
Figure 51: EtherCAT netANALYZER Wireshark Telegram Display	55
Figure 52: EtherNet/IP Analysis, Hardware Assembly	56
Figure 53: EtherNet/IP Filter Data Capture	57

Figure 54: EtherNet/IP Data Capture Start	58
Figure 55: Ethernet/IP netANALYZER Analysis Conversion 1	59
Figure 56: EtherNet/IP Data Capture	61
Figure 57: EtherNet/IP netANALYZER Entry Screen	63
Figure 58: EtherNet/IP netANALYZER Filter cifX → Slave 3	64
Figure 59: EtherNet/IP netANALYZER Direction of Signal Flow	65
Figure 60: EtherNet/IP netANALYZER Filter Slave 3 → cifX	66
Figure 61: netANALYZER Timing Analysis window	67
Figure 62: netANALYZER Timing-Auto-Scale	68
Figure 63: EtherNet/IP Port Settings for cycle time, Timing window A	68
Figure 64: EtherNet/IP Port Settings for the propagation time from the cifX to slave 3 through slaves 1 and 2, Timing window B	68
Figure 65: EtherNet/IP Port Settings for Propagation Time to Slave 3, Timing window C	69
Figure 66: EtherNet/IP Port Settings for the propagation time through Slave 1 and 2 to the cifX, Timing window D	69
Figure 67: Main Window of netANALYZER	69
Figure 68: EtherNet/IP, Cycle Time for Telegram Direction cifX to Slave 3	70
Figure 69: EtherNet/IP, Cycle Time for Telegram Direction Slave 3 to cifX	71
Figure 70: EtherNet/IP, Cycle Time of Slave 3	72
Figure 71: EtherNet/IP, Propagation Time Slave 2 and 1 for Telegram Direction Slave 3 to cifX	73
Figure 72: netANALYZER Entry Screen	74
Figure 73: Start Data Capture	75
Figure 74: pcap Conversion 1	75
Figure 75: EtherNet/IP netANALYZER Wireshark Telegram Display	77
Figure 76: Switch off Hardware Filters	78
Figure 77: Extended Software Filters	79
Figure 78: Extended Software Filters for cyclic Ethernet/IP Telegrams	80
Figure 79: Extended Software Filters for cyclic Ethernet/IP Telegrams and Ping	80
Figure 80: netANALYZER Main Window Ethernet/IP Netload Analysis	81
Figure 81: Netload Analysis for Ethernet/IP Telegrams (Start-up Phase) and Ping	82
Figure 82: Netload Analysis for Ethernet/IP Telegrams (Start-up Phase after Power Return)	83
Figure 83: sercos Analysis, Hardware Assembly	84
Figure 84: SERCOS III netANALYZER Entry Screen	85
Figure 85: SERCOS III netANALYZER SERCOS III Filter Settings	86
Figure 86: SERCOS III netANALYZER GPIO Settings	87
Figure 87: netANALYZER Timing Analysis window	87
Figure 88: netANALYZER Timing-Auto-Scale	88
Figure 89: netANALYZER Port-Selection	88
Figure 90: Sercos Settings Timing Analysis Window A	88
Figure 91: Sercos Settings Timing Analysis Window B	89
Figure 92: Sercos Settings Timing Analysis Window C	89
Figure 93: Sercos Settings Timing Analysis Window D	90
Figure 94: netANALYZER Start Analysis Cycle	90
Figure 95: SERCOS III netANALYZER Ring Delay Time	91
Figure 96: netANALYZER ConClk Cycle Time at Slave 1	92
Figure 97: Cycle Time Master Data Telegram Output Master	93
Figure 98: Cycle Time Master Data Telegram after passing through 3 Slaves	94
Figure 99: SERCOS III netANALYZER Analysis Start	95
Figure 100: Start Data Capture	95
Figure 101: pcap Conversion 1	96
Figure 102: SERCOS III netANALYZER Wireshark Telegram Display	98
Figure 103: Modbus/TCP Analysis, Hardware Assembly	99
Figure 104: Modbus/TCP netANALYZER Entry Screen	100
Figure 105: Modbus/TCP netANALYZER Filter 1	101
Figure 106: Modbus/TCP netANALYZER Filter 1 Test	102
Figure 107: Modbus/TCP netANALYZER Filter 2	103
Figure 108: Modbus/TCP netANALYZER Filter 3	104
Figure 109: Modbus/TCP netANALYZER Start Timing Analysis	105

Figure 110: netANALYZER Timing Analysis window	105
Figure 111: netANALYZER Timing-Auto-Scale	106
Figure 112: Modbus/TCP netANALYZER Measuring Window Settings 1	106
Figure 113: Modbus/TCP netANALYZER Start / Stop Window B	106
Figure 114: Modbus/TCP netANALYZER Start / Stop Window C	107
Figure 115: Modbus/TCP netANALYZER Start / Stop Window D	107
Figure 116: netANALYZER main window	108
Figure 117: Modbus/TCP netANALYZER Analysis Window A	108
Figure 118: Modbus/TCP netANALYZER Analysis Window B	109
Figure 119: Modbus/TCP netANALYZER Analysis Window B	110
Figure 120: Modbus/TCP netANALYZER Analysis Window C	110
Figure 121: Modbus/TCP netANALYZER Analysis Window D	111
Figure 122: Modbus/TCP netANALYZER Analysis Start	113
Figure 123: Start Data Capture	113
Figure 124: pcap Conversion 1	114
Figure 125: Modbus/TCP netANALYZER Wireshark Telegram Display	116
Figure 126: Switch off Hardware Filters	117
Figure 127: Extended Software Filters	118
Figure 128: Extended Software Filters for cyclic Modbus/TCP Telegrams	119
Figure 129: Extended Software Filters for cyclic MODBUS/TCP Telegrams and Ping	120
Figure 130: netANALYZER Main Window MODBUS/TCP Netload Analysis	121
Figure 131: Network Load for cyclic MODBUS/TCP Telegrams and Ping	122
Figure 132: Netload Analysis for Modbus/TCP Telegrams (Start-up Phase after Power Return)	123

10.2 List of Tables

Table 1: List of Revisions	4
Table 2: Overview of Measuring Examples	10
Table 3: Description File Settings	13

10.3 Contacts

Headquarters

Germany

Hilscher Gesellschaft für
Systemautomation mbH
Rheinstrasse 15
65795 Hattersheim
Phone: +49 (0) 6190 9907-0
Fax: +49 (0) 6190 9907-50
E-Mail: info@hilscher.com

Support

Phone: +49 (0) 6190 9907-99
E-Mail: de.support@hilscher.com

Subsidiaries

China

Hilscher Systemautomation (Shanghai) Co. Ltd.
200010 Shanghai
Phone: +86 (0) 21-6355-5161
E-Mail: info@hilscher.cn

Support

Phone: +86 (0) 21-6355-5161
E-Mail: cn.support@hilscher.com

France

Hilscher France S.a.r.l.
69500 Bron
Phone: +33 (0) 4 72 37 98 40
E-Mail: info@hilscher.fr

Support

Phone: +33 (0) 4 72 37 98 40
E-Mail: fr.support@hilscher.com

India

Hilscher India Pvt. Ltd.
New Delhi - 110 065
Phone: +91 11 43055431
E-Mail: info@hilscher.in

Italy

Hilscher Italia S.r.l.
20090 Vimodrone (MI)
Phone: +39 02 25007068
E-Mail: info@hilscher.it

Support

Phone: +39 02 25007068
E-Mail: it.support@hilscher.com

Japan

Hilscher Japan KK
Tokyo, 160-0022
Phone: +81 (0) 3-5362-0521
E-Mail: info@hilscher.jp

Support

Phone: +81 (0) 3-5362-0521
E-Mail: jp.support@hilscher.com

Korea

Hilscher Korea Inc.
Suwon, Gyeonggi, 443-734
Phone: +82 (0) 31-695-5515
E-Mail: info@hilscher.kr

Switzerland

Hilscher Swiss GmbH
4500 Solothurn
Phone: +41 (0) 32 623 6633
E-Mail: info@hilscher.ch

Support

Phone: +49 (0) 6190 9907-99
E-Mail: ch.support@hilscher.com

USA

Hilscher North America, Inc.
Lisle, IL 60532
Phone: +1 630-505-5301
E-Mail: info@hilscher.us

Support

Phone: +1 630-505-5301
E-Mail: us.support@hilscher.com